

SATA Slim

D150Q Series

Customer:	
Customer	
Part Number:	
InnoDisk	
Part Number:	
InnoDisk	
Model Name:	
Date:	

InnoDisk	Customer
Approver	Approver

the total solution for industrial flash storage



Table of contents

REVISION HISTORY	2
LIST OF FIGURES	
1. PRODUCT OVERVIEW	
1.1 INTRODUCTION OF INNODISK SATA SLIM D150Q	6
1.2 PRODUCT VIEW	6
1.3 PRODUCT MODELS	
1.4 SATA INTERFACE	
1.5 CAPACITY	
2. THEORY OF OPERATION	
2.1 OVERVIEW	
2.2 SATA II CONTROLLER	
2.3 ERROR DETECTION AND CORRECTION	
2.4 WEAR-LEVELING	
2.5 BAD BLOCKS MANAGEMENT	
3. INSTALLATION REQUIREMENTS	
3.1 SATA SLIM D150Q PIN DIRECTIONS	
3.2 ELECTRICAL CONNECTIONS FOR SATA SLIM D150Q	
3.3 DEVICE DRIVE	
4. SPECIFICATIONS	10
4.1 CE AND FCC COMPATIBILITY	10
4.2 RoHS Compliance	10
4.3 ENVIRONMENTAL SPECIFICATIONS	10
4.3.1 Temperature Ranges	10
4.3.2 Humidity	10
4.3.3 Shock and Vibration	10
4.3.4 Mean Time between Failures (MTBF)	10
4.4 ENDURANCE	11
4.5 Transfer Mode	11
4.6 PIN ASSIGNMENT	12
4.7 MECHANICAL DIMENSIONS	13
4.8 WEIGHT	13
4.9 Performance	13
4.10 SEEK TIME	13
4.11 Hot Plug	13
4.12 NAND FLASH MEMORY	14

1.4



4.13 ELECTRICAL SPECIFICATIONS	14
4.13.1 Power Requirement	14
4.13.2 Power Consumption	14
4.14 DEVICE PARAMETERS	14
4.15 WRITE PROTECT SWITCH	14
5. SUPPORTED ATA COMMANDS	15
5.1 SUPPORTED ATA COMMANDS	15
5.1.1 Check Power Mode	16
5.1.2 IDENTIFY DEVICE	17
5.1.3 IDLE	26
5.1.4 Idle Immediate	27
5.1.5 SMART	29
5.1.6 Read Multiple	33
5.1.7 Read Sector(s)	35
5.1.8 Read Verify Sector	37
5.1.9 Read DMA	39
5.1.10 Set Multiple Mode	40
5.1.11 Set Sleep Mode	42
5.1.12 Flush Cache	43
5.1.13 Standby	45
5.1.14 Standby Immediate	47
5.1.15 Write Multiple	48
5.1.16 Write Sector	51
5.1.17 Write DMA	53
5.1.18 Execute Device Diagnostic	55
5.1.19 Security Set Password	56
5.1.20 Security Unlock	58
5.1.21 Security Erase Prepare	60
5.1.22 Security Erase Unit	62
5.1.23 Security Freeze Lock	64
5.1.24 Security Disable Password	66

1.4



REVISION HISTORY

Revision	Description	Date
Preliminary	First Released	March 2011
Rev. 1.0	Modify the performance	April 2011
Rev. 1.1	Add the device parameters of 2GB and 32GB	May 2011
Rev. 1.2	Update SMART data structure and weight information	July 2011
Rev. 1.21	Updated mechanical drawing	AUG, 2012
Rev. 1.3	Separated into TSOP and BGA versions	AUG, 2012
Rev, 1.4	Added write protect switch information	SEP, 2012

Datasheet, SEP, 2012



List of Figures

FIGURE 1: INNODISK SATA SLIM D150Q	6
FIGURE 2: INNODISK SATA SLIM D150Q BLOCK DIAGRAM	7
FIGURE 3: SIGNAL SEGMENT AND POWER SEGMENT	9
FIGURE 4: SATA SLIM D150Q MECHANICAL DIMENSIONS	13

5 1.4



1. Product Overview

1.1 Introduction of InnoDisk SATA Slim D150Q

InnoDisk SATA Slim D150Q is designed with standard SATA interface (7+15 SATA connector), which could support most platforms with standard SATA port. Besides, with its smaller dimension, SATA Slim D150Q is an alternative solution of 2.5" SSD for those embedded system that may have mechanical and space concerns. InnoDisk SATA Slim D150Q operates under SATA II (3.0Gb/s) protocol with good performance, the sustain read/write can reach up to 130/125MB per second (max).

InnoDisk SATA Slim D150Q is also suitable in industrial field. It effectively reduces the booting time of operation system and the power consumption is less than hard disk drive (HDD). InnoDisk SATA Slim D150Q complies with ATA protocol, no additional drivers are required, and the SATA Slim can be configured as a boot device or data storage device.

1.2 Product View



Figure 1: InnoDisk SATA Slim D150Q (BGA)

1.3 Product Models

InnoDisk SATA Slim D150Q is available in follow capacities.

SATA Slim D150Q BGA 02GB ~ 64GB

1.4 SATA Interface

InnoDisk SATA Slim D150Q support SATA II interface, and compliant with Serial ATA Gen 1 and Gen 2 specification (Gen2 supports 1.5Gbps /3.0Gbps data rate). SATA connector uses a 7-pin signal segment and a 15-pin power segment.

1.5 Capacity

SATA Slim D150Q provides unformatted from 2GB up to 64GB capacities within SLC Flash IC.



2. Theory of operation

2.1 Overview

Figure 2 shows the operation of InnoDisk SATA Slim D150Q from the system level, including the major hardware blocks.




Figure 2: InnoDisk SATA SLIM D150Q Block Diagram

InnoDisk SATA Slim D150Q integrates a SATA II controller and NAND flash memories. Communication with the host occurs through the host interface, using the standard ATA protocol. Communication with the flash device(s) occurs through the flash interface.

2.2 SATA II Controller

The SATA II controller is 3.0 Gbps (Gen. 2), and support hot-plug. The Serial ATA physical, link and transport layers are compliant with Serial ATA Gen 1 and Gen 2 specification (Gen 2 supports 1.5Gbps/3.0Gbps data rate). The controller has 8 channels for flash interface.

The controller is equipped with 96KB of internal memory. 64 KB of memory is used for data buffer, and 32 KB is used for general purpose. The internal memory can also be used as an intermediate memory for storing data blocks during a wear-leveling procedure. There are 40KB of internal memory is used for code. A 10KB internal boot ROM includes basic routines for accessing the flash memories and for loading the main code into the internal memory.

2.3 Error Detection and Correction

Highly sophisticated Error Correction Code algorithms are implemented. The ECC unit consists of the Parity Unit (parity-byte generation) and the Syndrome Unit (syndrome-byte computation). This unit implements an algorithm that can correct 16 bits per 1024 bytes in an ECC block. Code-byte generation during write operations, as well as error detection during read operation, is implemented on the fly without any speed penalties.



2.4 Wear-Leveling

Flash memory can be erased within a limited number of times. This number is called the *erase cycle limit* or *write endurance limit* and is defined by the flash array vendor. The erase cycle limit applies to each individual erase block in the flash device.

InnoDisk SATA Slim D150Q uses a static wear-leveling algorithm to ensure that consecutive writes of a specific sector are not written physically to the same page/block in the flash. This spreads flash media usage evenly across all pages, thereby extending flash lifetime.

2.5 Bad Blocks Management

Bad Blocks are blocks that contain one or more invalid bits whose reliability are not guaranteed. The Bad Blocks may be presented while the SSD is shipped, or may generate during the life time of the SSD. When the Bad Blocks is detected, it will be flagged, and not be used anymore. The SSD implement Bad Blocks management and replacement, Error Correct Code to avoid data error occurred. The functions will be enabled automatically to transfer data from Bad Blocks to spare blocks, and correct error bit. After the reserved block less than 40, the SSD will be locked, and cannot be written anymore.



3. Installation Requirements

3.1 SATA Slim D150Q Pin Directions




Figure 3: Signal Segment and Power Segment

3.2 Electrical Connections for SATA Slim D150Q

A Serial ATA device may be either directly connected to a host or connected to a host through a cable. For connection via cable, the cable should be no longer than 1 meter. The SATA interface has a separate connector for the power supply. Please refer to the pin description for further details.

3.3 Device drive

No additional device drives are required. The InnoDisk SATA Slim D150Q can be configured as a boot device.



4. Specifications

4.1 CE and FCC Compatibility

InnoDisk SATA Slim D150Q conforms to CE and FCC requirements.

4.2 RoHS Compliance

InnoDisk SATA Slim D150Q is fully compliant with RoHS directive.

4.3 Environmental Specifications

4.3.1 Temperature Ranges

Operating Temperature Range:

Standard Grade: 0°C ~ +70°C

Industrial Grade: -40°C ~ +85°C

Storage Temperature Range:

- Standard Grade: -55°C to +95°C

4.3.2 Humidity

Relative Humidity: 10-95%, non-condensing

4.3.3 Shock and Vibration

Table 1: Shock/Vibration Testing for InnoDisk SATA Slim D150Q

Reliability	eliability Test Conditions Reference Standa	
Vibration	7 Hz to 2K Hz, 20G, 3 axes	IEC 68-2-6
Mechanical Shock	Duration: 0.5ms, 1500G, 3 axes	IEC 68-2-27

4.3.4 Mean Time between Failures (MTBF)

Table 2 summarizes the MTBF prediction results for various InnoDisk SATA Slim D150Q configurations. The analysis was performed using a RAM Commander[™] failure rate prediction.

- Failure Rate: The total number of failures within an item population, divided by the total number of life units expended by that population, during a particular measurement interval under stated condition.
- Mean Time between Failures (MTBF): A basic measure of reliability for repairable items: The mean number of life units during which all parts of the item perform within their specified limits, during a particular measurement interval under stated conditions.



Table 2: InnoDisk SATA Slim D150Q MTBF

Product	Condition	MTBF (Hours)
InnoDisk SATA SLIM D150Q	Telcordia SR-332 GB, 25°C	>4,000,000

4.4 Endurance

Data Retention: 10 years.

Wear-Leveling Algorithm: support. Bad Blocks Management: Support

Error Correct Code: Support

4.5 Transfer Mode

InnoDisk SATA Slim D150Q support following transfer mode:

PIO Mode 0~4.

Ultra DMA 0~6.

Serial ATA I 1.5Gbps

Serial ATA II 3.0Gbps



4.6 Pin Assignment

InnoDisk SATA Slim D150Q uses a micro SATA pin-out. Table 3 details the pin name, types and contact order of the two internal micro SATA plug options. A brief description is also included for signal, ground and power pins. There are total of 7 pins in the signal segment and 9 pins in the power segment.

Table 3: InnoDisk SATA Slim D150Q Pin Assignment

Name	Туре	Description
S1	GND	Ground
S2	A+	Differential Cianal Dair A
S3	A-	Differential Signal Pair A
S4	GND	Ground
S5	B-	Differential Cinnal Dair D
S6	B+	Differential Signal Pair B
S7	GND	Ground
Key and	Spacing separ	ate signal and power segments
P1	NC	NC
P2	NC	NC
P3	NC	NC
P4	GND	Ground
P5	GND	Ground
P6	GND	Ground
P7	V5	5V Power, Pre-Charge
P8	V5	5V Power
P9	V5	5V Power
P10	GND	Ground
P11	DAS/DSS	Device Activity Signal / Disable Staggered Spinup
P12	GND	Ground
P13	NC	NC
P14	NC	NC
P15	NC	NC



4.7 Mechanical Dimensions




Figure 4: SATA Slim D150Q mechanical dimensions (*Tolerance is ±0.1mm)

4.8 Weight

9g±2g

4.9 Performance

Produc	t name	2GB	4GB	8GB	16GB	32GB	64GB
D150Q	Sequential Read	34 MB/S	62MB/S	110MB/S	125MB/S	130MB/S	130MB/S
BGA	Sequential Write	26 MB/S	36MB/S	72MB/S	107MB/S	130MB/S	130MB/S

4.10 Seek Time

InnoDisk SATA Slim D150Q is not a magnetic rotating design. There is no seek or rotational latency required.

4.11 Hot Plug

The SSD support hot plug function and can be removed or plugged-in during operation. User has to avoid hot plugging the SSD which is configured as boot device and installed operation system.

Surprise hot plug : The insertion of a SATA device into a backplane (combine signal and power) that has power present. The device powers up and initiates an OOB sequence.

Surprise hot removal: The removal of a SATA device from a powered backplane, without first being placed in a quiescent state.



4.12 NAND Flash Memory

InnoDisk SATA Slim D150Q uses Single Level Cell (SLC) NAND flash memory, which is non-volatility, high reliability which has 100,000 program/erase times and high speed memory storage.

4.13 Electrical Specifications

4.13.1 Power Requirement

Table 4: InnoDisk SATA Slim D150Q Power Requirement

Item	Symbol	Rating	Unit
Input voltage	V_{IN}	+5DC +- 5% 500mA (max.)	V

4.13.2 Power Consumption

Table 5: Power Consumption

Mode	Power Consumption
Read	180mA (max.)
Write	200mA (max.)
Idle	110mA (max.)

4.14 Device Parameters

SATA Slim D150Q device parameters listed in Table 7.

Table 6: Device parameters

Capacity	Cylinders	Heads	Sectors	LBA	User capacity(MB)
2GB	3897	16	63	3928176	1918MB
4GB	7773	16	63	7835184	3825MB
8GB	15525	16	63	15649200	7641MB
16GB	16383	16	63	31277232	15272MB
32GB	16383	16	63	62533296	30533MB
64GB	16383	16	63	125206528	61136MB

4.15 Write protect switch

InnoDisk SATA SLIM D150Q has a write protect switch on itself, user can set the device in locked mode for read access only.







5. Supported ATA Commands

5.1 Supported ATA Commands

InnoDisk SATA Slim D150Q supports the commands listed in Table 7.

Table 7: ATA Commands

Common d Nome	O a d a		PAR	AMET	ERS U	SED	
Command Name	Code	sc	SN	CY	DR	HD	FT
CHECK POWER MODE	E5h	0	Х	Х	0	Х	Х
DEVICE CONFIGURATION OVERLAY	B1h	Х	Х	Х	0	Х	0
EXECUTE DIAGNOSTICS	90h	Х	Х	Х	0	Х	Х
FLUSH CACHE	E7h	Х	Х	Х	0	Х	Х
FLUSH CACHE EXT	EAh	Х	Х	Х	0	Х	Х
IDENTIFY DEVICE	ECh	Х	Х	Х	0	Х	Х
IDLE	E3h	0	Х	Х	0	Х	Х
IDLE IMMEDIATE	E1h	Х	Х	Х	0	Х	Х
NOP	00h	F	F	F	0	Х	0
INITIALIZE DEVICE PARAMETERS	91h	0	Х	Х	0	0	Х
READ BUFFER	E4h	Х	Х	Х	0	Х	Х
READ DMA	C8h or C9h	0	0	0	0	0	Х
READ DMA EXT	25h	0	0	0	0	0	Х
READ FPDMA QUEUED	60h	0	0	0	0	0	0
READ LOG EXT	2Fh	0	0	0	0	0	0
READ MULTIPLE	C4h	0	0	0	0	0	Х
READ MULTIPLE EXT	29h	0	0	0	0	0	Х
READ NATIVE MAX ADDRESS	F8h	Х	Х	Х	0	Х	Х
READ NATIVE MAX ADDRESS EXT	27h	Х	Х	Х	0	Х	Х
READ SECTOR(S)	20h or 21h	0	0	0	0	0	Х
READ SECTOR(S) EXT	24h	0	0	0	0	0	Х
READ VERIFY SECTOR(S)	40h or 41h	0	0	0	0	0	Х
READ VERIFY SECTOR(S) EXT	42h	0	0	0	0	0	Х
RECALIBRATE	10h	Х	Х	Х	0	Х	Х
SECURITY DISABLE PASSWORD	F6h	Х	Х	Х	0	Х	Х
SECURITY ERASE PREPARE	F3h	Х	Х	Х	0	Х	Х
SECURITY ERASE UNIT	F4h	Х	Х	Х	0	Х	Х
SECURITY FREEZE LOCK	F5h	Х	Х	Х	0	Х	Х
SECURITY SET PASSWORD	F1h	Х	Х	Х	0	Х	Х
SECURITY UNLOCK	F2h	Х	Χ	Χ	0	Х	Х



- ,							
SEEK	7xh	Х	Х	0	0	0	Х
SET FEATURES	EFh	0	Х	Х	0	Х	0
SET MAX	F9h	0	0	0	0	0	0
SET MAX ADDRESS EXT	37h	0	0	0	0	0	Х
SET MULTIPLE MODE	C6h	0	Х	Х	0	Х	Х
SLEEP	E6h	Х	Х	Х	0	Х	Х
SMART	B0h	Х	Х	0	0	Х	0
STANDBY	E2h	Х	Х	Х	0	Х	Х
STANDBY IMMEDIATE	E0h	Х	Х	Х	0	Х	Х
WRITE BUFFER	E8h	Х	Х	Х	0	Х	Х
WRITE DMA	CAh or CBh	0	0	0	0	0	Х
WRITE DMA EXT	35h	0	0	0	0	0	Х
WRITE DMA FUA EXT	3Dh	0	0	0	0	0	Х
WRITE FPDMA QUEUED	61h	0	0	0	0	0	0
WRITE LOG EXT	3Fh	0	0	0	0	0	Х
WRITE MULTIPLE	C5h	0	0	0	0	0	Х
WRITE MULTIPLE EXT	39h	0	0	0	0	0	Х
WRITE MULTIPLE FUA EXT	CEh	0	0	0	0	0	Х
WRITE SECTOR(S)	30h or 31h	0	0	0	0	0	Х
WRITE SECTOR(S) EXT	34h	0	0	0	0	0	Х
WRITE VERIFY	3Ch	0	0	0	0	0	0

Note:

O = Valid, X = Don't care

SC = Sector Count Register

SN = Sector Number Register

CY = Cylinder Low/High Register

DR = DEVICE SELECT Bit (DEVICE/HEAD Register Bit 4)

HD = HEAD SELECT Bit (DEVICE/HEAD Register Bit 3-0)

FT = Features Register

5.1.1 Check Power Mode

5.1.1.1 Command Code

E5h

5.1.1.2 Feature Set

Power Management feature set.

- This command is mandatory for devices.
- -This command is mandatory when the Power Management feature set is implemented.

5.1.1.3 Protocol

Non-data command

5.1.1.4 Inputs



Table 8: Check power mode command for inputs information
--

Register	7	6	5	4	3	2	1	0
Features	Na							
Sector Count	Na							
LBA Low	Na							
LBA Mid	Na							
LBA High	Na							
Device	obs	Na	Obs	DEV	Na	Na	Na	Na
Command	E5h							

Device register

DEV shall specify the selected device.

5.1.2 IDENTIFY DEVICE

5.1.2.1 Command Code

ECh

5.1.2.2 Feature Set

General feature set

- -Mandatory for all devices.
- -Devices implementing the PACKET Command feature set

5.1.2.3 Protocol

PIO data-in

5.1.2.4 Inputs

Table 9: Identify device command for inputs information

Register	7	6	5	4	3	2	1	0
Features	Na							
Sector Count	Na							
LBA Low	Na							
LBA Mid	Na							
LBA High	Na							
Device	obs	Na	Obs	DEV	Na	Na	Na	Na
Command	ECh							

Device register

DEV shall specify the selected device.

5.1.2.5 Outputs

5.1.2.6 Normal outputs

Table 10: Identify device command for normal outputs information

Register	7	6	5	4	3	2	1	0
Error	Na							
Sector Count	Na	Na						
LBA Low	Na							



LBA Mid	Na							
LBA High	Na							
Device	obs	Na	obs	DEV	Na	Na	Na	Na
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR

Device register

DEV shall indicate the selected device.

Status register

BSY shall be cleared to zero indicating command completion.

DRDY shall be set to one.

DF (Device Fault) shall be cleared to zero.

DRQ shall be cleared to zero.

ERR shall be cleared to zero.

5.1.2.7 Prerequisites

DRDY set to one.

5.1.2.8 Description

The IDENTIFY DEVICE command enables the host to receive parameter information from the device. When the command is issued, the device sets the BSY bit to one, prepares to transfer the 256 words of device identification data to the host, sets the DRQ bit to one, clears the BSY bit to zero, and asserts INTRQ if nIEN is cleared to zero. The host may then transfer the data by reading the Data register. Table 8 defines the arrangement and meaning of the parameter words in the buffer. All reserved bits or words shall be zero.

Some parameters are defined as a 16-bit value. A word that is defined as a 16-bit value places the most significant bit of the value on signal line DD15 and the least significant bit on signal line DD0. Some parameters are defined as 32-bit values (e.g. words (61:60)). Such fields are transfer using two successive word transfers. The device will first transfer the least significant bits, bits (15:0) of the value, on signal lines DD(15:0) respectively. After the least significant bits have been transferred, the most significant bits, bits(31:16) of the value, shall be transferred on DD(15:0) respectively. Some parameters are defined as a string of ASCII characters.

Table 11: Identify device command parameters

Word	Value	F/V	Description
0	0040h	F X X X V	General configuration 15
1	XXXXh	F	Number of logical cylinders
2	C837h	V	Specific configuration
3	0010h	F	Number of logical heads
4-5	0000h	Х	Retired
6	003Fh	F	Number of logical sector per logical track



Beyond yo	our imagi	nation	IIIIIODISK SATA SIIIII D 130Q
7-8	0000h		Reserved for assignment by the CompactFlash_ Association
9	0000h	Х	Retired
10-19	XXXXh	F	Serial number (20 ASCII characters)
20-21	0000h	Х	Retired
22	0000h	Х	Obsolete
23-26	XXXXh	F	Firmware revision (8 ASCII characters)
27-46	XXXXh	F	Model number (40 ASCII characters)
47	8010h	F F	15-8 80h 7-0 00h = Reserved 01h = Maximum number of 1 sectors on READ/WRITE MULTIPLE commands
48	0000h		Reserved
		F	Capabilities 15-14 Reserved for the IDENTIFY PACKET DEVICE command. 13 1 = Standby timer values as specified in this standard are supported
49	2F00h	F F	0 = Standby timer values shall be managed by the device 12 Reserved for the IDENTIFY PACKET DEVICE command. 11 1 = IORDY supported 0 = IORDY may be supported
		F F X	10 1 = IORDY may be disabled 9 1 = LBA supported 8 1 = DMA supported. 7-0 Retired
50	4000h	F F X F	Capabilities 15 Shall be cleared to zero. 14 Shall be set to one. 13-2 Reserved. 1 Obsolete 0 Shall be set to one to indicate a device specific Standby timer value minimum.
51	0000h	F	15-8 PIO data transfer cycle timing mode 7-0 Reserved
52	0000h	Х	Obsolete
53	0007h	F F	15-3 Reserved 2 1 = the fields reported in word 88 are valid 0 = the fields reported in word 88 are not valid
		F	1 1 = the fields reported in words 70:64 are valid 0 = the fields reported in words 70:64 are not valid 0 = the fields reported in words 70:64 are not valid
		Х	0 1 = the fields reported in words 58:54 are valid 0 = the fields reported in words 58:54 are not valid
54	XXXXh	Х	Number of current cylinders
55	0010h	Х	Number of current heads
56	003Fh	Х	Number of current sector per track
57-58	XXXXh	Х	Current capacity in sectors
59	0110h	V V	15-9 Reserved 8 1 = Multiple sector setting is valid 7-0 xxh = Setting for number of sectors that shall be transferred per interrupt on R/W Multiple command
60-61	XXXXh	F	Total number of user addressable sectors
62	0000h	X	Obsolete
63	0X07h		15-11 Reserved



Beyond yo	our imagi	nation	INNODISK SATA SIIM D'150Q
		V	10 1 = Multiword DMA mode 2 is selected
		.,	0 = Multiword DMA mode 2 is not selected
		V	9 1 = Multiword DMA mode 1 is selected 0 = Multiword DMA mode 1 is not selected
		V	8 1 = Multiword DMA mode 0 is selected
			0 = Multiword DMA mode 0 is not selected
			7-3 Reserved
		F	2 1 = Multiword DMA mode 2 and below are supported
		F	1 1 = Multiword DMA mode 1 and below are supported 0 1 = Multiword DMA mode 0 is supported
6.4	0002h	Г	15-8 Reserved
64	0003h	F	7-0 Advanced PIO modes supported
65	0078h	F	Minimum Multiword DMA transfer cycle time per word
66	0078h	F	Manufacturer's recommended Multiword DMA transfer cycle time
67	0078h	F	Minimum PIO transfer cycle time without flow control
		F	Minimum PIO transfer cycle time with IORDY flow control
68	0078h	F	
69-70	0000h		Reserved
71-74	0000h		Reserved for the IDENTIFY PACKET DEVICE command
75	001Fh		Queue depth
		F	15-5 Reserved 4-0 Maximum queue depth - 1
		Г	Serial ATA Capabilities
			15-11 Reserved for Serial ATA
		F	10 1 = Supports Phy Event Counts
		F	9 1 = Supports receipt of host initiated power management requests
76	0106h	F	8 1 = Supports the NCQ feature set
		_	7-3 Reserved for Serial ATA 1 - Supports SATA Cond Signaling Speed (3.0Ch/s)
		F	2 1 = Supports SATA Gen2 Signaling Speed (3.0Gb/s) 1 1 = Supports SATA Gen1 Signaling Speed (1.5Gb/s)
		F	0 Shall be cleared to zero
77	0000h		Reserved for Serial ATA
			Serial ATA feature supported
			15-7 Reserved for Serial ATA
		F	6 1 = Device supports Software Settings Preservation
70	00445	_	5 Reserved for Serial ATA
78	0044h	F F	 4 1 = Device supports in-order data delivery 3 1 = Device supports initiating power management
		F	2 1 = Device supports initiating power management 2 1 = Device supports DMA Setup auto-activation
		F	1 1 = Device supports non-zero buffer offsets
		F	0 Shall be cleared to zero
			Serial ATA feature enabled
		V	15-7 Reserved for Serial ATA
		V	6 1 = Software Settings Preservation enabled 5 Reserved for Serial ATA
79	0040h	V	4 1 = In-order data delivery enabled
		V	3 1 = Device initiated power management enabled
		V	2 1 = DMA Setup auto-activation enabled
		V F	1 1 = Non-zero buffer offsets enabled
		Г	0 Shall be cleared to zero Major version number 0000h or FFFFh = device does not report version
			15 Reserved
		F	14 Reserved for ATA/ATAPI-14
80	01F0h	F	13 Reserved for ATA/ATAPI-13
	011	F	12 Reserved for ATA/ATAPI-12
		F	11 Reserved for ATA/ATAPI-11 10 Reserved for ATA/ATAPI-10
		F	9 Reserved for ATA/ATAPI-10



Beyond yo	our imagi		InnoDisk SATA Slim D150Q
		F	8 Reserved for ATA/ATAPI-8
		F	7 1 = supports ATA/ATAPI-7
		F	6 1 = supports ATA/ATAPI-6
		F	5 1 = supports ATA/ATAPI-5
		F	4 1 = supports ATA/ATAPI-4
		F	3 Obsolete
		X	2 Obsolete
		X	1 Obsolete
		, ,	0 Reserved
81	0000h	F	Minor version number
			Command and feature sets supported
		Х	15 Obsolete
		F	14 1 = NOP command supported
		F	13 1 = READ BUFFER command supported
		F	12 1 = WRITE BUFFER command supported
		Х	11 Obsolete
		F	10 1 = Host Protected Area feature set supported
		F	9 1 = DEVICE RESET command supported
		F	8 1 = SERVICE interrupt supported
82	746Bh	F	7 1 = release interrupt supported
		F	6 1 = look-ahead supported
		F	5 1 = write cache supported
		F	4 Shall be cleared to zero to indicate that the PACKET Command
		F	feature set is not supported.
		F	3 1 = mandatory Power Management feature set supported
		F	2 1 = Removable Media feature set supported
		F.	1 1 = Security Mode feature set supported
		•	0 1 = SMART feature set supported
			Command and feature sets supported
		F	15 Shall be cleared to zero
		F	14 Shall be set to one
		F	13 1 = The FLUSH CACHE EXT command is supported
		F	12 Shall be set to one to indicate that the mandatory FLUSH CACHE
		F	command is supported
		F	11 1 = The DCO feature set is supported
		F	10 1 = The Boo feature set is supported 10 1 = The 48-bit Address feature set is suported
		F	9 1 = The AAM feature set is supported
83	7D08h		8 1 = SET MAX security extension supported
00	7 50011	F	7 Reserved
		F	6 1 = SET FEATURES subcommand required to spinup after
		F	·
		F	power-up 5
		F	4 1 = Removable Media Status Notification feature set supported
		F	
		F	3 1 = Advanced Power Management feature set supported
			2 1 = CFA feature set supported
			1 1 = READ/WRITE DMA QUEUED supported
			0 1 = DOWNLOAD MICROCODE command supported



Beyond yo	our imagi	nation	InnoDisk SATA Slim D150Q
		F	15 Shall be cleared to zero
		F	14 Shall be set to one
		F	13 1 = The IDLE IMMEDIATE command with UNLOAD feature is
			supported
		X	12-11 Reserved for TLC
		F	10-9 Obsolete
		F	8 1 = The 64-bit World wide name is supported
84	4040h	F	7 1 = The WRITE DMA QUEUED FUA EXT command is supported
04	4040h	F	6 1 = The WRITE DMA FUA EXT and WRITE MULTIPLE FUA EXT commands are supported
		F	5 1 = The GPL feature set is supported
		F	4 1 = The Streaming feature set is supported
		F.	3 1 = The Media Card Pass Through Command feature set is
		F	supported
			1 = Media serial number is supported
			1 1 = SMART self-test supported
			0 1 = SMART error logging supported
85	746Xh		Command and feature sets supported or enable
		Х	15 Obsolete
		F	14 1 = The NOP command is supported
		F	13 1 = The READ BUFFER command is supported
		F	12 1 = The WRITE BUFFER command is supported
		X	11 Obsolete
		V F	10 1 = HPA feature set is supported
		V	9 Shall be cleared to zero to indicate that the DEVICE RESET
		V	command is not supported 8
		V	7 1 = The certific interrupt is enabled
		V	6 1 = Read look-ahead is enabled
		F	5 1 = The volatile write cache is enabled
		F	4 Shall be cleared to zero to indicate that the PACKET Command
		Х	feature set is not supported.
		V	3 Shall be set to one to indicate that the mandatory Power
		V	Management feature is supported
			2 Obsolete
			1 1 = The Security feature set is enabled
			0 1 = The SMART feature set is enabled Command and feature sets supported or enable
86	BC00h	F	15 1 = Words 119-120 are valid
		'	14 Reserved
		F	13 1 = FLUSH CACHE EXT command supported
		F.	12 1 = FLUSH CACHE command supported
		F	11 1 = The DCO feature set is supported
		F	10 1 = The 48-bit Address feature set is supported
		V	9 1 = The AAM feature set is enable
		V	8 1 = The SET MAX security extension is enabled by SET MAX SET
			PASSWORD
		F	7 Reserved for Address Offset Reserved Area Boot Method
		V	6 1 = SET FEATURES subcommand required to spin-up after
		X	power-up
		V F	5 1 = The PUIS feature set is enabled 4 Obsolete
		F	3 1 = The APM feature set is enabled
		F	2 1 = The CFA feature set is supported
			1 1 = The CFA feature set is supported
			0 1 = The DOWNLOAD MICROCODE command is supported
87	4040h		Command and feature sets supported or enabled
01	10 1011	F	15 Shall be cleared to zero
		F	14 Shall be set to one
		F	13 1 = The IDLE IMMEDIATE command with UNLOAD feature is



Beyond yo	our imagi	nation	INNODISK SATA SIIM D'150Q
			supported
		Х	12-11 Reserved for TLC
		F	10-9 Obsolete
		F	8 1 = The 64-bit World wide name is supported
		F	7 1 = The WRITE DMA QUEUED FUA EXT command is supported
		F	6 1 = The WRITE DMA FUA EXT and WRITE MULTIPLE FUA EXT
		X	commands are supported
		V	5 1 = The GPL feature set is supported
		V	4 Obsolete
		F	3 1 = The Media Card Pass Through Command feature set is
		F	supported
			2 1 = Media serial number is supported
			1 1 = SMART self-test supported
			0 1 = SMART error logging supported Ultra DMA modes
88	XX7Fh		
		W	15 Reserved
		V	14 1 = Ultra DMA mode 6 is selected
		V	0 = Ultra DMA mode 6 is not selected
		V	13 1 = Ultra DMA mode 5 is selected 0 = Ultra DMA mode 5 is not selected
		V	12 1 = Ultra DMA mode 4 is selected
		V	0 = Ultra DMA mode 4 is selected
		V	11 1 = Ultra DMA mode 3 is selected
		V	0 = Ultra DMA mode 3 is not selected
		V	10 1 = Ultra DMA mode 2 is selected
		V	0 = Ultra DMA mode 2 is selected
		V	9 1 = Ultra DMA mode 1 is selected
		V	0 = Ultra DMA mode 1 is not selected
		V	8 1 = Ultra DMA mode 0 is selected
		·	0 = Ultra DMA mode 0 is not selected
			7 Reserved
		F	6 1 = Ultra DMA mode 6 and below are supported
		F	5 1 = Ultra DMA mode 5 and below are supported
		F	4 1 = Ultra DMA mode 4 and below are supported
		F	3 1 = Ultra DMA mode 3 and below are supported
		F	2 1 = Ultra DMA mode 2 and below are supported
		F	1 1 = Ultra DMA mode 1 and below are supported
		F	0 1 = Ultra DMA mode 0 is supported
89	001Eh		15-8 Reserved
00	001211	F	7-0 Time required for Normal Erase mode SECURITY ERASE UNIT
			command
90	001Eh		15-8 Reserved
		F	7-0 Time required for Enhanced Erase mode SECURITY ERASE
			UNIT command
91	0000h	V	Current APM level value
92	FFFEh	V	Master Password Identifier
93	0000h	Х	Hardware reset result
			Current AAM value
94	0000h	F	15-8 Vendor's recommended AAM value
		V	7-0 Current AAM value
05.00	00001	V	Reserved
95-99	0000h		
100-103	XXXXh	X	Total Number of User Addressable Logical Sectors for 48-bit commands
			(QWord)
104-105	0000h		Reserved
106	4000h		Physical sector size / logical sector size
		F	15 Shall be cleared to zero
		F	14 Shall be set to one
		F	13 1 = Device has multiple logical sectors per physical sector



Beyond yo	our imagi	nation	INNODISK SATA SIIM D'150Q
		F	12 1 = Device Logical Sector longer than 256 Words 11-4 Reserved
		F	3-0 2x logical sectors per physical sector
107	0000h	F	Inter-seek delay for ISO 7779 standard acoustic testig
108-111	XXXXh	F	Worldwide name
112-115	0000h		Reserved
116	0000h		Reserved for TLC
117-118	0000h	F	Logical sector size (DWord)
119	4000h	F F F F	Commands and feature sets supported (Continued from words 84:82) 15 Shall be cleared to zero 14 Shall be set to one 13-6 Reserved 5 1= The Free-fall Control feature set is supported 4 1 = The DOWNLOAD MICROCODE command with mode 3 is supported 3 1 = The READ LOG DMA EXT and WRITE LOG DMA EXT commands are supported 2 1 = The WRITE UNCORRECTABLE EXT command is supported 1 1 = The Write-Read-Verify feature set is supported Reserved for DDT
120	4000h	F V F F V	Commands and feature sets supported or enabled (Continued from words 87:85) 15 Shall be cleared to zero 14 Shall be set to one 13-6 Reserved 5 1= The Free-fall Control feature set is enabled 4 1 = The DOWNLOAD MICROCODE command with mode 3 is supported 3 1 = The READ LOG DMA EXT and WRITE LOG DMA EXT commands are supported 2 1 = The WRITE UNCORRECTABLE EXT command is supported 1 1 = The Write-Read-Verify feature set is enabled 0 Reserved for DDT
121-126	0000h		Reserved for expended supported and enabled settings
127	0000h	Х	Obsolete
128	0021h	V F V V V F	Security status 15-9 Reserved 8 Security level 0 = High, 1 = Maximum 7-6 Reserved 5 1 = Enhanced security erase supported 4 1 = Security count expired 3 1 = Security frozen 2 1 = Security locked 1 1 = Security enabled 0 1 = Security supported
129-159	0000h	Х	Vendor specific
160	0000h	F F V F	CFA power mode 15 Word 160 supported 14 Reserved 13 CFA power mode 1 is required for one or more commands implemented by the device 12 CFA power mode 1 disabled 11:0 Maximum current in ma
161-167	0000h		Reserved for the Compact Flash Association
168	0003h		15:4 Reserved



Beyond yo	our imagi		IIIIODISK SATA SIIIII D 150Q
		F	3:0 Device Nominal Form Factor
169	0000h		DATA SET MANAGEMENT is supported
		F	15:1 Reserved 0 1 = the Trim bit in the DATA SET MANAGEMENT is supported
170-173	0000h	F	Additional Product Identifier (ATA String)
		•	ν ο,
174-175	0000h		Reserved
176-205	0000h	V	Current media serial number (ATA String)
206	0000h	V	SCT Command Transport
		X	15:12 Vendor Specific 11:6 Reserved
		F	5 The SCT Data Tables command is supported
		F	4 The SCT Feature Control command is supported
		F	3 The SCT Error Recovery Control command is supported
		F	2 The SCT Write Same command is supported
		F	1 Obsolete 0 The SCT Command Transport is supported
207-208	0000h		Reserved for CE-ATA
209	4000h		Alignment of logical blocks within a physical block
203	400011		15 Shall be cleared to zero
		_	14 Shall be set to one
		F	13:0 Logical sector offset within the first physical sector where the first
210-211	0000h	V	logical sector is placed Write-Read-Verify Sector Count Mode 3 (DWord)
212-213	0000h	F	Write-Read-Verify Sector Count Mode 2 (DWord)
214	0000h		NV Cache Capabilities
214	UUUUN	F	15:12 NC+V Cache feature set version
		F	11:8 NV Cache Power Mode feature set version
			7:5 Reserved
		V	4 1 = NV Cache feature set enabled
		V	3:2 Reserved 1 1 = NV Cache Power Mode feature set enabled
		F	0 1 = NV Cache Power Mode feature set supported
215-216	0000h	V	NV Cache Size in Logical Blocks (DWord)
217	0001h	F	Nominal media rotation rate
218	0000h		Reserved
219	0000h	F	NV Cache Options
			15:8 Reserved
000	00001	V	7:0 Device Estimated Time to Spin Up in Seconds 15:8 Reserved
220	0000h	V	7:0 Write-Read-Verify feature set current mode
221	0000h		Reserved
222	101Fh		Transport major version number
		_	0000h or FFFFh = device does not report version
		F	15:12 Transport Type 0h = Parallel
			1h = Serial
			2h-Fh = Reserved
			Parallel Serial
			11:5 Reserved Reserved
		F	4 Reserved SATA Rev 2.6
		F	3 Reserved SATA Rev 2.5
		F F	2 Reserved SATA II: Extensions
		F	1 ATA/ATAPI-7 SATA 1.0a 0 ATA8-APT ATA8-AST
		· ·	7170701



Deyona ye			
223	0000h	F	Transport minor version number
224-233	0000h		Reserved for CE-ATA
234	0000h	F	Minimum number of 512-byte data blocks per DOWNLOAD MICROCODE command for mode 3
235	0000h	F	Maximum number of 512-byte data blocks per DOWNLOAD MICROCODE command for mode 3
236-254	0000h		Reserved
255	XXXXh	V V	Integrity word 15-8 Checksum 7-0 Checksum Validity Indicator
1/			

Kev

F/V – Fixed/variable content

F = the content of the word is fixed and does not change. For removable media devices, these values may change when media is removed or changed.

V = the contents of the word is variable and may change depending on the state of the device or the commands executed by the device.

X = the content of the word may be fixed or variable.

5.1.3 IDLE

5.1.3.1.1 Command Code

E3h

5.1.3.1.2 Feature Set

Power Management Feature Set.

5.1.3.1.3 Protocol

Non-Data

5.1.3.1.4 Inputs

Values other than zero in the Sector Count register when the IDLE command is issued shall determine the time period programmed into the Standby timer.

Table 12: Idle command for inputs information

Register	7	6	5	4	3	2	1	0			
Features	Na	Na									
Sector Count	Timer p	Timer period value									
LBA Low	Na	Na									
LBA Mid	Na										
LBA High	Na										
Device	Obs	Na	Obs	DEV	Na	Na	Na	Na			
Command	E3h										

Device register-

DEV shall specify the selected device.

Table 13: Idle command sector count register contents information

Sector Count register contents	Corresponding timeout period
0 (00h)	Timeout disabled
1-240 (01h-F0h)	(value*5)s
241-251 (F1h-FBh)	((Value-240)*30)min



252 (FCh)	21min
253 (FDh)	Period between 8 and 12 hrs
254 (FEh)	Reserved
255 (FFh)	21 min 15 s
NOTE – Times are approximate	

5.1.3.1.5 Normal Outputs

Table 14: Idle command for normal outputs information

Register	7	6	5	4	3	2	1	0
Error	Na							
Sector Count	Na							
LBA Low	Na							
LBA Mid	Na							
LBA High	Na							
Device	obs	Na	obs	DEV	Na	Na	Na	Na
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR

Device Register-

DEV shall indicate the selected device.

Status register-

BSY will be cleared to zero indicating command completion.

DRDY will be set to one.

DF (Device Fault) will be cleared to zero.

DRQ shall be cleared to zero.

ERR shall be cleared to zero.

5.1.3.1.6 Error Outputs

Table 15: Idle command for error outputs information

Register	7	6	5	4	3	2	1	0		
Error	Na	Na	Na	Na	Na	ABRT	Na	Na		
Sector Count	Na	Na								
LBA Low	Na	Na								
LBA Mid	Na	Na								
LBA High	Na									
Device	obs	Na	obs	DEV	Na					
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR		

5.1.3.1.7 Prerequisites

DRDY set to one

5.1.3.1.8 Description

The IDLE command allows the host to place the device in the idle mode and also set the Standby timer.

5.1.4 Idle Immediate



5.1.4.1.1 Command Code

E1h

5.1.4.1.2 Feature Set

Power Management Feature Set.

5.1.4.1.3 Protocol

Non-Data

5.1.4.1.4 Inputs

Table 16: Idle immediate command for inputs information

Register	7	6	5	4	3	2	1	0
Features	Na							
Sector Count	Na							
LBA Low	Na							
LBA Mid	Na							
LBA High	Na							
Device	obs	Na	obs	DEV	Na	Na	Na	Na
Command	E1h							

Device register-

DEV shall specify the selected device.

5.1.4.1.5 Normal Outputs

Table 17: Idle immediate command for normal outputs information

Register	7	6	5	4	3	2	1	0
Error	Na							
Sector Count	Na							
LBA Low	Na							
LBA Mid	Na							
LBA High	Na							
Device	obs	Na	obs	DEV	Na	Na	Na	Na
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR

Device Register-

DEV shall indicate the selected device.

Status register-

BSY will be cleared to zero indicating command completion.

DRDY will be set to one.

DF (Device Fault) will be cleared to zero.

DRQ shall be cleared to zero.

ERR shall be cleared to zero.

5.1.4.2 Prerequisites

DRDY set to one

5.1.4.3 Description

The IDLE IMMEDIATE command allows the host to immediately place the device in the idle



mode.

5.1.5 SMART

Individual SMART commands are identified by the value placed in the Feature register.

Table 18: SMART Feature register values

Value	Command
D0h	SMATR Read Data
D8h	SMART ENABLE OPERATIONS
D9h	SMART DISABLE OPERATIONS

5.1.5.1 SMART Read Data

5.1.5.1.1 Command Code

B0h with a Feature register value of D0h

5.1.5.1.2 Feature Set

Smart Feature Set

- Operation when the SMART feature set is implemented.

5.1.5.1.3 Protocol

PIO data-in

5.1.5.1.4 Inputs

Table 19: SMART command for inputs information

Register	7	6	5	4	3	2	1	0					
Features		D0h											
Sector Count		Na											
LBA Low		Na											
LBA Mid				4F	-h								
LBA High				C	2h								
Device	Obs	Na	obs	DEV	Na	Na	Na	Na					
Command	B0h												

Device register-

DEV shall specify the selected device.

5.1.5.1.5 Normal Outputs

Table 20: SMART command for normal outputs information

Register	7	6	5	4	3	2	1	0					
Error		Na											
Sector Count		Na											
LBA Low		Na											
LBA Mid		Na											
LBA High				N	la								
Device	Obs	Na	obs	DEV	Na	Na	Na	Na					
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR					

Device Register-



DEV shall indicate the selected device.

Status register-

BSY will be cleared to zero indicating command completion.

DRDY will be set to one.

DF (Device Fault) will be cleared to zero.

DRQ shall be cleared to zero.

ERR shall be cleared to zero.

5.1.5.1.6 Prerequisites

DRDY set to one. SMART enabled.

5.1.5.1.7 Description

This command returns the Device SMART data structure to the host.

Table 21: ID of SMART data structure

	+0	+1	+2	+3	+4	+5	+6	+7	+8	+9	+10	+11
Attribute Name	ID	Fla	igs	Init	Worst		Ra	w Attribute Value				Rsv
Read Error Rate	01h	0Bh	00h	64h	64h	FFh	FFh	FFh	00h	00h	00h	00h
Throughput Performance	02h	05h	00h	64h	64h	00h	00h	00h	00h	00h	00h	00h
Spin Up Time	03h	07h	00h	64h	64h	00h	00h	00h	00h	00h	00h	00h
Reallocated Sector Count	05h	13h	00h	64h	64h	00h	00h	00h	00h	00h	00h	00h
Seek Error Rate	07h	0Bh	00h	64h	64h	00h	00h	00h	00h	00h	00h	00h
Seek Time performance	08h	05h	00h	64h	64h	00h	00h	00h	00h	00h	00h	00h
Power-On hours Count	09h	12h	00h	64h	64h	(1)	00h	00h	00h	00h	00h
Spin Retry Count	0Ah	13h	00h	64h	64h	00h	00h	00h	00h	00h	00h	00h
Drive Power Cycle Count	0Ch	12h	00h	64h	64h	(2	2)	00h	00h	00h	00h	00h
SATA PHY Error Count	A8h	12h	00h	64h	64h	(3)	00h	00h	00h	00h	00h
Bad Block Count	AAh	03h	00h	64h	64h	00h	00h	(4	1)	(:	5)	00h
Erase Count	ADh	12h	00h	64h	64h	(6)	(7	7)	(6)	(7)	00h
Bad Cluster Table Count	AFh	03h	00h	64h	64h	(8)	00h	00h	00h	00h	00h
Unexpected Power Loss Count	C0h	12h	00h	64h	64h	(9)	00h	00h	00h	00h	00h
Temperature	C2h	22h	00h	(10)	64h	(10)	00h	(11)	00h	(12)	00h	00h
Current Pending Sector Counter	C5h	12h	00h	64h	64h	00h	00h	00h	00h	00h	00h	00h
Write Head	F0h	13h	00h	64h	64h	00h	00h	00h	00h	00h	00h	00h

Table 22: Smart command for average/max erase count information

	SMART	DI 101
	F: Fixed V:Variable X: None	
Byte	F/V	Description
0-188	X	
189-190	F	Total Bad Block Number of System(190:MSB 189:LSB)
191-192	F	Later Bad Block Number of System(192:MSB 191:LSB)
193-198	X	
199-200.203	F	Average Erase Count(203:MSB 199:LSB)



201-202.204	V	Maximum Erase Count(204:MSB 201:LSB)
205-510	X	
511	V	Check Sum

When the Maximum erase count is 255 bigger than average erase count, the wear-leveling will be executed.

5.1.5.2 SMART ENABLE OPERATIONS

5.1.5.2.1 Command Code

B0h with a Feature register value of D8h

5.1.5.2.2 Feature Set

Smart Feature Set

5.1.5.2.3 Protocol

Non-data

5.1.5.2.4 Inputs

Table 23: SMART Enable command for inputs information

Register	7	6	5	4	3	2	1	0						
Features		D8h												
Sector Count		Na												
LBA Low		Na												
LBA Mid				4F	-h									
LBA High				C	2h									
Device	Obs	Na	obs	DEV	Na	Na	Na	Na						
Command	B0h													

Device register-

DEV shall specify the selected device.

5.1.5.2.5 Normal Outputs

Table 24: SMART command for normal outputs information

Register	7	6	5	4	3	2	1	0					
Error	Na												
Sector Count		Na											
LBA Low		Na											
LBA Mid				N	la								
LBA High				N	la								
Device	Obs	Na	obs	DEV	Na	Na	Na	Na					
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR					

Device Register-

DEV shall indicate the selected device.

Status register-

BSY will be cleared to zero indicating command completion.

DRDY will be set to one.



DF (Device Fault) will be cleared to zero.

DRQ shall be cleared to zero.

ERR shall be cleared to zero.

5.1.5.2.6 Prerequisites

DRDY set to one.

5.1.5.2.7 Description

This command enables access to all SMART capabilities within device.

5.1.5.3 SMART DISABLE OPERATIONS

5.1.5.3.1 Command Code

B0h with a Feature register value of D9h

5.1.5.3.2 Feature Set

Smart Feature Set

5.1.5.3.3 Protocol

Non-data

5.1.5.3.4 Inputs

Table 25: SMART DISABLE Command for inputs information

Register	7	6	5	4	3	2	1	0						
Features		D9h												
Sector Count		Na												
LBA Low		Na												
LBA Mid				4F	-h									
LBA High				C	2h									
Device	Obs	Na	obs	DEV	Na	Na	Na	Na						
Command	B0h													

Device register-

DEV shall specify the selected device.

5.1.5.3.5 Normal Outputs

Table 26: SMART command for normal outputs information

Register	7	6	5	4	3	2	1	0						
Error		Na												
Sector Count		Na												
LBA Low		Na												
LBA Mid				N	la									
LBA High				N	la									
Device	Obs	Na	obs	DEV	Na	Na	Na	Na						
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR						

Device Register-

DEV shall indicate the selected device.

Status register-

BSY will be cleared to zero indicating command completion.



DRDY will be set to one.

DF (Device Fault) will be cleared to zero.

DRQ shall be cleared to zero.

ERR shall be cleared to zero.

5.1.5.3.6 Prerequisites

DRDY set to one. SMART enabled.

5.1.5.3.7 Description

This command disables all SMART capabilities within device.

5.1.6 Read Multiple

5.1.6.1 Command Code

C4h

5.1.6.2 Protocol

PIO data-in

5.1.6.3 Inputs

Table 27: Read multiple command for inputs information

		-		-									
Register	7	6	5	4	3	2	1	0					
Features	Na	Na											
Sector Count	Sector (Sector Count											
LBA Low	LBA(7:0	LBA(7:0)											
LBA Mid	LBA(15	:8)											
LBA High	LBA(23	:16)											
Device	obs	Na	obs	DEV	LBA(27	:24)							
Command	C4h												

Sector Count-

Number of sectors to be transferred. A value of 00h specifies that 256 sectors are to be transferred.

LBA Low-

Starting LBA bits (7:0).

LBA Mid-

Starting LBA bits (15:8)

LBA High-

Starting LBA bits (23:16)

Device -

DEV shall specify the selected device.

Bit (3:0) starting LBA bits (27:24)

5.1.6.4 Normal Output

Table 28: Read multiple command for normal output information

Register	7	6	5	4	3	2	1	0
Error	Na							



Sector	Count	Na							
LBA Lo)W	Na							
LBA M	id	Na							
LBA Hi	gh	Na	Na						
Device		obs	Na	obs	DEV	Na	Na	Na	Na
Status		BSY	DRDY	DF	Na	DRQ	Na	Na	ERR

Device register-

DEV shall specify the selected device.

Status register

BSY will be cleared to zero indicating command completion

DRDY will be set to one.

DF (Device Fault) will be cleared to zero.

DRQ will be cleared to zero

ERR will be cleared to zero.

5.1.6.5 Error Outputs

An unrecoverable error encountered during the execution of this command results in the termination of the command. The Command Block registers contain the address of the sector where the first unrecoverable error occurred. The amount of data transferred us indeterminate.

Table 29: Read multiple command for error output information

Register	7	6	5	4	3	2	1	0
Error	Na	UNC	МС	IDNF	MCR	ABRT	NM	Obs
Sector Count	Na	Na						
LBA Low	LBA(7:0	LBA(7:0)						
LBA Mid	LBA(15	LBA(15:8)						
LBA High	LBA(23	LBA(23:16)						
Device	obs	obs Na obs DEV LBA(27:24)						
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR

Error register-

UNC shall be set to one if data is uncorrectable.

IDNF shall be set to one if a user-accessible address is requested could not be found.

LBA Low, LBA Mid, and LBA High, Device

Shall be written with the address of first unrecoverable error.

Status register

BSY will be cleared to zero indicating command completion

DRDY will be set to one.

DF (Device Fault) will be cleared to zero.

DRQ will be cleared to zero

ERR will be set to one if an Error register bit is set to one.

5.1.6.6 Prerequisites



DRDY set to one.

5.1.6.7 Description

This command reads the number of sectors specified in the sector Count register.

The number of sectors per block is defined by the content of word 59 in the IDENTIFY DEVICE response.

5.1.7 Read Sector(s)

5.1.7.1 Command Code

20h

5.1.7.2 Protocol

PIO data-in

5.1.7.3 Inputs

Table 30: Read sector command for inputs information

Register	7	6	5	4	3	2	1	0	
Features	Na	Na							
Sector Count	Sector	Sector Count							
LBA Low	LBA(7:0	LBA(7:0)							
LBA Mid	LBA(15	LBA(15:8)							
LBA High	LBA(23	LBA(23:16)							
Device	obs	Na	obs	DEV	LBA(27	:24)			
Command	20h								

Sector Count-

Number of sectors to be transferred. A value of 00h specifies that 256 sectors are to be transferred.

LBA Low-

Starting LBA bits (7:0).

LBA Mid-

Starting LBA bits (15:8)

LBA High-

Starting LBA bits (23:16)

Device -

DEV shall specify the selected device.

Bit (3:0) starting LBA bits (27:24)

5.1.7.4 Normal Output

Table 31: Read sector command for normal outputs information

Register	7	6	5	4	3	2	1	0
Error	Na							
Sector Count	Na							
LBA Low	Na							
LBA Mid	Na							



LBA High	Na							
Device	obs	Na	obs	DEV	Na	Na	Na	Na
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR

Device register-

DEV shall specify the selected device.

Status register

BSY will be cleared to zero indicating command completion

DRDY will be set to one.

DF (Device Fault) will be cleared to zero.

DRQ will be cleared to zero

ERR will be cleared to zero.

5.1.7.5 Error Outputs

An unrecoverable error encountered during the execution of this command results in the termination of the command. The Command Block registers contain the address of the sector where the first unrecoverable error occurred. The amount of data transferred us indeterminate.

Table 32: Read sector command for error outputs information

Register	7	6	5	4	3	2	1	0
Error	Na	UNC	MC	IDNF	MCR	ABRT	NM	Obs
Sector Count	Na	Na						
LBA Low	LBA(7:0	LBA(7:0)						
LBA Mid	LBA(15	LBA(15:8) LBA(23:16)						
LBA High	LBA(23							
Device	obs	obs Na obs DEV LBA(27:24)						
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR

Error register-

UNC shall be set to one if data is uncorrectable.

IDNF shall be set to one if a user-accessible address is requested could not be found.

LBA Low, LBA Mid, and LBA High, Device

Shall be written with the address of first unrecoverable error.

Status register

BSY will be cleared to zero indicating command completion

DRDY will be set to one.

DF (Device Fault) will be cleared to zero.

DRQ will be cleared to zero

ERR will be set to one if an Error register bit is set to one.

5.1.7.6 Prerequisites

DRDY set to one.

5.1.7.7 Description

This command reads from 1 to 256 sectors as specified in the Sector Count register. A sector



count of 0 requests 256 sectors. This transfer shall begin at the sector specified in the LBA Low, LBA Mid, LBA High, and Device registers.

The DRQ bit is always set to one prior to data transfer regardless of the presence or absence of an error condition. The device shall interrupt for each DRQ block transferred.

5.1.8 Read Verify Sector

5.1.8.1 Command Code

40h

5.1.8.2 Protocol

Non-data

5.1.8.3 Inputs

Table 33: Read verify sector command for inputs information

Register	7	6	5	4	3	2	1	0			
Features	Na	Na									
Sector Count	Sector (Sector Count									
LBA Low	LBA(7:0	LBA(7:0)									
LBA Mid	LBA(15	:8)									
LBA High	LBA(23	:16)									
Device	obs	obs Na obs DEV LBA(27:24)									
Command	40h										

Sector Count-

Number of sectors to be transferred. A value of 00h specifies that 256 sectors are to be transferred.

LBA Low-

Starting LBA bits (7:0).

LBA Mid-

Starting LBA bits (15:8)

LBA High-

Starting LBA bits (23:16)

Device -

The LBA bit shall be set to one to specify the address is an LBA.

DEV shall specify the selected device.

Bit (3:0) starting LBA bits (27:24)

5.1.8.4 Normal Output

Table 34: Read verify sector command for normal output information

Register	7	6	5	4	3	2	1	0
Error	Na							
Sector Count	Na							
LBA Low	Na							
LBA Mid	Na							



LBA High	Na							
Device	obs	Na	obs	DEV	Na	Na	Na	Na
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR

DEV shall specify the selected device.

Status register

BSY will be cleared to zero indicating command completion

DRDY will be set to one.

DF (Device Fault) will be cleared to zero.

DRQ will be cleared to zero

ERR will be cleared to zero.

5.1.8.5 Error Outputs

An unrecoverable error encountered during the execution of this command results in the termination of the command. The Command Block registers contain the address of the sector where the first unrecoverable error occurred.

Table 35: Read verify sector command for normal output information

Register	7	6	5	4	3	2	1	0			
Error	Na	UNC	МС	IDNF	MCR	ABRT	NM	Obs			
Sector Count	Na	Na									
LBA Low	LBA(7:0	LBA(7:0)									
LBA Mid	LBA(15	:8)									
LBA High	LBA(23	:16)									
Device	obs	obs Na obs DEV LBA(27:24)									
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR			

Error register-

UNC shall be set to one if data is uncorrectable.

IDNF shall be set to one if a user-accessible address could not be found.

LBA Low, LBA Mid, and LBA High, Device

Shall be written with the address of first unrecoverable error.

Status register

BSY will be cleared to zero indicating command completion

DRDY will be set to one.

DF (Device Fault) will be cleared to zero.

DRQ will be cleared to zero

ERR will be set to one if an Error register bit is set to one.

5.1.8.6 Prerequisites

DRDY set to one.

5.1.8.7 Description

This command is identical to the READ SECTOR(s) command, except that the device shall have read the data from the SSD, the DRQ bit is never set to one, and no data is transferred to

the host.

5.1.9 Read DMA

5.1.9.1 Command Code

C8h

5.1.9.2 Protocol

DMA

5.1.9.3 Inputs

Table 36: Read DMA command for inputs information

Register	7	6	5	4	3	2	1	0			
Features	Na	Na									
Sector Count	Sector (Sector Count									
LBA Low	LBA(7:0	LBA(7:0)									
LBA Mid	LBA(15	:8)									
LBA High	LBA(23	:16)									
Device	obs	obs Na obs DEV LBA(27:24)									
Command	C4h										

Sector Count-

Number of sectors to be transferred. A value of 00h specifies that 256 sectors are to be transferred.

LBA Low-

Starting LBA bits (7:0).

LBA Mid-

Starting LBA bits (15:8)

LBA High-

Starting LBA bits (23:16)

Device -

DEV shall specify the selected device.

Bit (3:0) starting LBA bits (27:24)

5.1.9.4 Normal Output

Table 37: Read DMA command for normal output information

Register	7	6	5	4	3	2	1	0				
Error	Na	Na										
Sector Count	Na	la										
LBA Low	Na											
LBA Mid	Na											
LBA High	Na											
Device	obs	Na	obs	DEV	Na	Na	Na	Na				
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR				

Device register-



DEV shall specify the selected device.

Status register

BSY will be cleared to zero indicating command completion

DRDY will be set to one.

DF (Device Fault) will be cleared to zero.

DRQ will be cleared to zero

ERR will be cleared to zero.

5.1.9.5 Error Outputs

An unrecoverable error encountered during the execution of this command results in the termination of the command. The Command Block registers contain the address of the sector where the first unrecoverable error occurred. The amount of data transferred us indeterminate.

Table 38: Read DMA command for error output information

Register	7	6	5	4	3	2	1	0			
Error	ICRC	UNC	МС	IDNF	MCR	ABRT	NM	Obs			
Sector Count	Na	Na .									
LBA Low	LBA(7:0	_BA(7:0)									
LBA Mid	LBA(15	:8)									
LBA High	LBA(23	:16)									
Device	Obs	Na	obs	DEV	LBA(27:24)						
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR			

Error register-

ICRC shall be set to one if an interface CRC error has occurred during an Ultra DMA data transfer. The content of this bit is not applicable for Multiword DMA transfers.

UNC shall be set to one if data is uncorrectable.

IDNF shall be set to one if a user-accessible address could not be found.

LBA Low, LBA Mid, and LBA High, Device

Shall be written with the address of first unrecoverable error.

Status register

BSY will be cleared to zero indicating command completion

DRDY will be set to one.

DF (Device Fault) will be cleared to zero.

DRQ will be cleared to zero

ERR will be set to one if an Error register bit is set to one.

5.1.9.6 Prerequisites

DRDY set to one. The host shall initialize the DMA channel.

5.1.9.7 Description

The READ DMA command allows the host to read data using the DMA data transfer protocol.

5.1.10 Set Multiple Mode



5.1.10.1 Command Code

C6h

5.1.10.2 Protocol

Non-data

5.1.10.3 Inputs

If the content of the Sector Count Register is not zero, then the Sector Count register contains the number of sectors per block for the device to be used on all following READ/WRITE MULTIPLE commands. The content of the Sector Count register shall be less than or equal to the value in bits (7:0) in word 47 in the IDENTIFY DEVICE information. The host should set the content of the Sector Count register to 1.

Table 39: Set multiple mode command for inputs information

Register	7	6	5	4	3	2	1	0			
Features	Na	Na									
Sector Count	Sector	Sector per block									
LBA Low	Na	Na									
LBA Mid	Na										
LBA High	Na										
Device	obs	Na	obs	DEV	Na						
Command	C6h										

5.1.10.4 Normal Output

Table 40: Set multiple mode command for normal output information

Register	7	6	5	4	3	2	1	0
Error	Na							
Sector Count	Na							
LBA Low	Na							
LBA Mid	Na							
LBA High	Na							
Device	obs	Na	obs	DEV	Na	Na	Na	Na
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR

Device register-

DEV shall specify the selected device.

Status register

BSY will be cleared to zero indicating command completion

DRDY will be set to one.

DF (Device Fault) will be cleared to zero.

DRQ will be cleared to zero

ERR will be cleared to zero.

5.1.10.5 Error Outputs

Table 41: Set multiple mode command for error outputs information

Danistan	7	C	_	1	2	2	4	_
Register	/	l n	ເລ	14	1.5			1 ()
	-	_	•	-	_	_	-	_



Error	Na	Na	obs	Na	Na	ABRT	Na	Na
Sector Count	Na							
LBA Low	Na							
LBA Mid	Na							
LBA High	Na							
Device	Obs	Na	obs	DEV	Na			
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR

Status register

BSY will be cleared to zero indicating command completion

DRDY will be set to one.

DF (Device Fault) will be cleared to one if a device fault has occurred.

DRQ will be cleared to zero

ERR will be set to one if an Error register bit is set to one.

5.1.10.6 Prerequisites

DRDY set to one.

5.1.10.7 Description

This command establishes the block count for READ MULTIPLE, READ MULTI EXT, WRITE MULTIPLE.

SSD can only support 1 sector per block.

5.1.11 Set Sleep Mode

5.1.11.1 Command Code

E6h

5.1.11.2 Protocol

Non-data

5.1.11.3 Inputs

Table 42: Set sleep mode for inputs information

Register	7	6	5	4	3	2	1	0
Features	Na							
Sector Count	Na							
LBA Low	Na							
LBA Mid	Na							
LBA High	Na							
Device	obs	Na	obs	DEV	Na			
Command	E6h							

Device register-

DEV shall specify the selected device.

5.1.11.4 Normal Output

Table 43: Set sleep mode for normal output information

	_	_	_	_	_	_		_
Register	l 7	16	l 5	1 4	l 3	2	l 1	()
rtogiotor	•	•		•		_	•	•



Error	Na							
Sector Count	Na							
LBA Low	Na							
LBA Mid	Na							
LBA High	Na							
Device	obs	Na	obs	DEV	Na	Na	Na	Na
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR

DEV shall specify the selected device.

Status register

BSY will be cleared to zero indicating command completion

DRDY will be set to one.

DF (Device Fault) will be cleared to zero.

DRQ will be cleared to zero

ERR will be cleared to zero.

5.1.11.5 Error Outputs

Table 44: Set sleep mode for error output information

Register	7	6	5	4	3	2	1	0
Error	Na	Na	Na	Na	Na	ABRT	Na	Na
Sector Count	Na							
LBA Low	Na							
LBA Mid	Na							
LBA High	Na							
Device	Obs	Na	obs	DEV	Na			
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR

Status register

BSY will be cleared to zero indicating command completion

DRDY will be set to one.

DF (Device Fault) will be set to one if a device fault has occurred.

DRQ will be cleared to zero

ERR will be set to one if an Error register bit is set to one.

5.1.11.6 Prerequisites

DRDY set to one.

5.1.11.7 Description

This command is the only way to cause the device to enter Sleep mode.

5.1.12 Flush Cache

5.1.12.1 Command Code

E7h

5.1.12.2 Protocol



Non-data

5.1.12.3 Inputs

Table 45: Flush cache command for inputs information

Register	7	6	5	4	3	2	1	0
Features	Na							
Sector Count	Na							
LBA Low	Na							
LBA Mid	Na							
LBA High	Na							
Device	obs	Na	obs	DEV	Na			
Command	E7h							

Device register-

DEV shall specify the selected device.

5.1.12.4 Normal Output

Table 46: Flush cache command for normal output information

Register	7	6	5	4	3	2	1	0
Error	Na							
Sector Count	Na							
LBA Low	Na							
LBA Mid	Na							
LBA High	Na							
Device	obs	Na	obs	DEV	Na	Na	Na	Na
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR

Device register-

DEV shall specify the selected device.

Status register

BSY will be cleared to zero indicating command completion

DRDY will be set to one.

DF (Device Fault) will be cleared to zero.

DRQ will be cleared to zero

ERR will be cleared to zero.

5.1.12.5 Error Outputs

Table 47: Flush cache command for error output information

Register	7	6	5	4	3	2	1	0
Error	Na	Na	Na	Na	Na	ABRT	Na	Na
Sector Count	Na							
LBA Low	LBA(7:0	LBA(7:0)						
LBA Mid	LBA(15	:8)						
LBA High	LBA(23	LBA(23:16)						
Device	Obs	Na	obs	DEV	LBA(27	:24)		



Status BSY DRDY DF Na DRQ Na Na ER

Error register-

ABRT may be set to one if the device is not able to complete the action requested by the command.

LBA Low, LBA Mid, and LBA High, Device

Shall be written with the address of first unrecoverable error.

Status register

BSY will be cleared to zero indicating command completion

DRDY will be set to one.

DF (Device Fault) will be cleared to one if a device fault has occurred.

DRQ will be cleared to zero

ERR will be set to one if an Error register bit is set to one.

5.1.12.6 Prerequisites

DRDY set to one.

5.1.12.7 Description

This command is used by the host to request the device to flush the write cache. If there is data in write cache, that data shall be written to the SSD. The BSY bit shall remain set to one until all data has been successfully written or an error occurs.

5.1.13 Standby

5.1.13.1 Command Code

F2h

5.1.13.2 Protocol

Non-data

5.1.13.3 Inputs

The value in the Sector Count register when the STANDBY command is issued shall determine the time period programmed into the Standby timer.

Table 48: Standby command for inputs information

Register	7	6	5	4	3	2	1	0	
Features	Na								
Sector Count	Time pe	eriod valu	ie						
LBA Low	Na								
LBA Mid	Na								
LBA High	Na								
Device	obs	Na	obs	DEV	Na				
Command	E2h	E2h							

Device register-

DEV shall specify the selected device.

5.1.13.4 Normal Output

Table 49: Standby command for normal output information



Register	7	6	5	4	3	2	1	0
Error	Na							
Sector Count	Na							
LBA Low	Na							
LBA Mid	Na							
LBA High	Na							
Device	obs	Na	obs	DEV	Na	Na	Na	Na
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR

DEV shall specify the selected device.

Status register

BSY will be cleared to zero indicating command completion

DRDY will be set to one.

DF (Device Fault) will be cleared to zero.

DRQ will be cleared to zero

ERR will be cleared to zero.

5.1.13.5 Error Outputs

Table 50: Standby command for error output information

Register	7	6	5	4	3	2	1	0
Error	Na	Na	Na	Na	Na	ABRT	Na	Na
Sector Count	Na							
LBA Low	Na							
LBA Mid	Na							
LBA High	Na							
Device	Obs	Na	obs	DEV	Na			
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR

Error register-

ABRT may be set to one if the device is not able to complete the action requested by the command.

Status register

BSY will be cleared to zero indicating command completion

DRDY will be set to one.

DF (Device Fault) will be set to one if a device fault has occurred.

DRQ will be cleared to zero

ERR will be set to one if an Error register bit is set to one.

5.1.13.6 Prerequisites

DRDY set to one.

5.1.13.7 Description

This command causes the device to enter the Standby mode.

If the Sector Count register is non-zero then Standby timer shall be enabled. The value in the



Sector Count register shall be used determine the time programmed into the Standby timer. If the Sector Count register is zero then the Standby timer is disabled.

5.1.14 Standby Immediate

5.1.14.1 Command Code

E0h

5.1.14.2 Protocol

Non-data

5.1.14.3 Inputs

Table 51: Standby immediate command for inputs information

Register	7	6	5	4	3	2	1	0
Features	Na							
Sector Count	Na							
LBA Low	Na							
LBA Mid	Na							
LBA High	Na							
Device	obs	Na	obs	DEV	Na			
Command	E0h							

Device register-

DEV shall specify the selected device.

5.1.14.4 Normal Output

Table 52: Standby immediate command for normal output information

Register	7	6	5	4	3	2	1	0
Error	Na							
Sector Count	Na							
LBA Low	Na							
LBA Mid	Na							
LBA High	Na							
Device	obs	Na	obs	DEV	Na	Na	Na	Na
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR

Device register-

DEV shall specify the selected device.

Status register

BSY will be cleared to zero indicating command completion

DRDY will be set to one.

DF (Device Fault) will be cleared to zero.

DRQ will be cleared to zero

ERR will be cleared to zero.

5.1.14.5 Error Outputs

Table 53: Standby immediate command for error output information



Register	7	6	5	4	3	2	1	0		
Error	Na	Na	Na	Na	Na	ABRT	Na	Na		
Sector Count	Na	Na Na								
LBA Low	Na	Na								
LBA Mid	Na	Na								
LBA High	Na									
Device	Obs	Na	obs	DEV	Na					
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR		

Error register-

ABRT may be set to one if the device is not able to complete the action requested by the command.

Status register

BSY will be cleared to zero indicating command completion

DRDY will be set to one.

DF (Device Fault) will be set to one if a device fault has occurred.

DRQ will be cleared to zero

ERR will be set to one if an Error register bit is set to one.

5.1.14.6 Prerequisites

DRDY set to one.

5.1.14.7 Description

This command causes the device to immediately enter the Standby mode.

5.1.15 Write Multiple

5.1.15.1 Command Code

C5h

5.1.15.2 Protocol

PIO data-out

5.1.15.3 Inputs

The LBA mid, LBA High, Device, and LBA Low specify the starting sector address to be written.

The Sector Count register specifies the number of sectors to be transferred.

Table 54: Write multiple command for inputs information

Register	7	6	5	4	3	2	1	0			
Features	Na	Na									
Sector Count	Sector (Sector Count									
LBA Low	LBA(7:0	LBA(7:0)									
LBA Mid	LBA(15	LBA(15:8)									
LBA High	LBA(23	:16)									
Device	obs	obs Na obs DEV LBA(27:24)									
Command	C5h										

Sector Count-



Number of sectors to be transferred. A value of 00h specifies that 256 sectors shall be transferred.

LBA Low-

Starting LBA bits (7:0)

LBA Mid-

Starting LBA bits (15:8)

LBA High-

Starting LBA bits (23:16)

Device -

The LBA bit shall be set to one to specify the address is an LBA.

DEV shall specify the selected device.

Bits(3:0) starting LBA bits (27:24)

5.1.15.4 Normal Output

Table 55: Write multiple command for normal output information

Register	7	6	5	4	3	2	1	0				
Error	Na	Na .										
Sector Count	Na	la .										
LBA Low	Na											
LBA Mid	Na	Na										
LBA High	Na											
Device	obs	Na	obs	DEV	Na	Na	Na	Na				
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR				

Device register-

DEV shall specify the selected device.

Status register

BSY will be cleared to zero indicating command completion

DRDY will be set to one.

DF (Device Fault) will be cleared to zero.

DRQ will be cleared to zero

ERR will be cleared to zero.

5.1.15.5 Error Outputs

An unrecoverable error encountered during the execution of this command results in the termination of the command. The Command Block register contain the address of the sector where the first unrecoverable error occurred. The amount of data transferred is indeterminate.

Table 56: Write multiple command for normal output information

Register	7	6	5	4	3	2	1	0			
Error	Na	WP	MC	IDNF	MCR	ABRT	NM	Na			
Sector Count	Na	Na									
LBA Low	LBA(7:0	LBA(7:0)									
LBA Mid	LBA(15:8)										



LBA High	LBA(23	LBA(23:16)								
Device	Obs	Obs Na obs DEV LBA(27:24)								
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR		

Error register-

IDNF shall be set to one if a user-accessible address could not be found. IDNF shall be set to one if an address outside of the range user-accessible address is requested if command aborted is not returned.

ABRT shall be set to one if an error, include an ICRC error, has occurred during an Ultra DMA data transfer. ABRT shall be set to one if an address outside of the range of user-accessible address is requested if IDNF is not set to one.

LBA Low, LBA Mid, and LBA High, Device -

Shall be written with the address of first unrecoverable error.

Status register

BSY will be cleared to zero indicating command completion

DRDY will be set to one.

DF (Device Fault) will be set to one if a device fault has occurred.

DRQ will be cleared to zero

ERR will be set to one if an Error register bit is set to one.

5.1.15.6 Prerequisites

DRDY set to one. If bit 8 of IDENTIFY DEVICE word 59 is cleared to zero, a successful SET MULTIPLE MODE command shall proceed a WRITE MULTIPLE command.

5.1.15.7 Description

This command writes the number of sectors specified in the Sector Count register.

The number of sectors per block is defined by the content of word 59 of the IDENTIFY DEVICE response.

When the WRITE MULTIPLE command is issued, the SECTOR Count register contains the number of sectors (not the number of blocks) requested. The device shall interrupt for each DRQ block transferred.

IF the number of requested sectors is not evenly divisible by the block count, as many full blocks as possible are transferred, followed by a final, partial block transfer. The partial block transfer is for n sectors, where:

N = Remainder (sector count / block count).

If the WRITE MULTIPLE command is received when WRITE MULTIPLE commands are disabled, the Write Multiple operation shall be rejected with command aborted.

Device errors encountered during WRITE MULTIPLE commands are posted after the attempted device write of the block or partial block transferred. The command ends with the sector in error, even if the error was in the middle of a block. Subsequent blocks are not transferred in the event of an error.

The contents of the Command Block Registers following the transfer of a data block that had a sector in error are undefined. The host should retry the transfer as individual requests to



obtain valid error information. Interrupt pending is set when the DRQ bit is set to one at the beginning of each block or partial block.

5.1.16 Write Sector

5.1.16.1 Command Code

30h

5.1.16.2 Protocol

PIO data-out

5.1.16.3 Inputs

The LBA mid, LBA High, Device, and LBA Low specify the starting sector address to be written.

The Sector Count register specifies the number of sectors to be transferred.

Table 57: Write sector command for inputs information

Register	7	6	5	4	3	2	1	0			
Features	Na	Na									
Sector Count	Sector	Sector Count									
LBA Low	LBA(7:0	LBA(7:0)									
LBA Mid	LBA(15	LBA(15:8)									
LBA High	LBA(23	:16)									
Device	obs	obs LBA obs DEV LBA(27:24)									
Command	30h										

Sector Count-

Number of sectors to be transferred. A value of 00h specifies that 256 sectors shall be transferred.

LBA Low-

Starting LBA bits (7:0)

LBA Mid-

Starting LBA bits (15:8)

LBA High-

Starting LBA bits (23:16)

Device -

The LBA bit shall be set to one to specify the address is an LBA.

DEV shall specify the selected device.

Bits(3:0) starting LBA bits (27:24)

5.1.16.4 Normal Output

Table 58: Write sector command for inputs information

Register	7	6	5	4	3	2	1	0
rtogistor	,			-			'	Ŭ
Error	Na							
Sector Count	Na							
LBA Low	Na							
LBA Mid	Na							



LBA High	Na	la la									
Device	obs	Na	obs	DEV	Na	Na	Na	Na			
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR			

DEV shall specify the selected device.

Status register

BSY will be cleared to zero indicating command completion

DRDY will be set to one.

DF (Device Fault) will be cleared to zero.

DRQ will be cleared to zero

ERR will be cleared to zero.

5.1.16.5 Error Outputs

An unrecoverable error encountered during the execution if this command results in the termination of the command. The Command Block registers contain the address of the sector where the first unrecoverable error occurred. The amount of data transferred is indeterminate.

Table 59: Write sector command for error outputs information

Register	7	6	5	4	3	2	1	0			
Error	Na	WP	МС	IDNF	MCR	ABRT	NM	Na			
Sector Count	Na	Na									
LBA Low	LBA(7:0	LBA(7:0)									
LBA Mid	LBA(15	LBA(15:8)									
LBA High	LBA(23	:16)									
Device	Obs	Na	obs	DEV	LBA(27:24)						
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR			

Error register-

IDNF shall be set to one if a user-accessible address could not be found. IDNF shall be set to one if an address outside of the range of user-accessible addresses is requested if command aborted is not returned.

ABRT shall be set to one if an error, including an ICRC error, has occurred during an Ultra DMA data transfer. ABRT shall be set to one if the device is not able to complete the action requested by the command. ABRT shall be set to one if an address outside of the range of user-accessible addresses is requested if IDNF is not set to one.

LBA Low, LBA Mid, and LBA High, Device

Shall be written with the address of first unrecoverable error.

Status register

BSY will be cleared to zero indicating command completion

DRDY will be set to one.

DF (Device Fault) will be set to one if a device fault has occurred.

DRQ will be cleared to zero

ERR will be set to one if an Error register bit is set to one.



5.1.16.6 Prerequisites

DRDY set to one.

5.1.16.7 Description

This command writes from 1 to 256 sectors as specified in the Sector Count register. A sector count of 0 requests 256 sectors. The device shall interrupt for each DRQ block transferred.

5.1.17 Write DMA

5.1.17.1 Command Code

CAh

5.1.17.2 Protocol

DMA

5.1.17.3 Inputs

The LBA Mid, LBA High, Device, and LBA Low specify the starting sector address to be written.

The Sector Count register specifies the number of sectors to be transferred.

Table 60: Write DMA command for input information

Register	7	6	5	4	3	2	1	0			
Features	Na	Na									
Sector Count	Sector	Sector Count									
LBA Low	LBA(7:0	LBA(7:0)									
LBA Mid	LBA(15	LBA(15:8)									
LBA High	LBA(23	:16)									
Device	obs	obs LBA obs DEV LBA(27:24)									
Command	CAh										

Sector Count-

Number of sectors to be transferred. A value of 00h specifies that 256 sectors shall be transferred.

LBA Low-

Starting LBA bits (7:0)

LBA Mid-

Starting LBA bits (15:8)

LBA High-

Starting LBA bits (23:16)

Device -

The LBA bit shall be set to one to specify the address is an LBA.

DEV shall specify the selected device.

Bits (3:0) starting LBA bits (27:24)

Normal Output

Table 61: Write DMA command for normal output information

Register	7	6	5	4	3	2	1	0
9								



Error	Na									
Sector Count	Na									
LBA Low	Na									
LBA Mid	Na	Na								
LBA High	Na									
Device	obs	Na	obs	DEV	Na	Na	Na	Na		
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR		

DEV shall specify the selected device.

Status register

BSY will be cleared to zero indicating command completion

DRDY will be set to one.

DF (Device Fault) will be cleared to zero.

DRQ will be cleared to zero

ERR will be cleared to zero.

5.1.17.4 Error Outputs

Table 62: Write DMA command for error outputs information

Register	7	6	5	4	3	2	1	0		
Error	ICRC	WP	МС	IDNF	MCR	ABRT	NM	Obs		
Sector Count	Na	Na								
LBA Low	LBA(7:0	LBA(7:0)								
LBA Mid	LBA(15	:8)								
LBA High	LBA(23	:16)								
Device	Obs	Na	obs	DEV	LBA(27:24)					
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR		

Error register-

ICRC shall be set to one if an interface CRC error has occurred during an Ultra DMA data transfer. The content of this bit is not applicable for Multiword DMA transfers.

IDNF shall be set to one if a user-accessible address could not be found. INDF shall be set to one if an address outside of the range of user-accessible address is requested if command aborted is not returned.

ABRT shall be set to one if an error, including an ICRC error, has occurred during an Ultra DMA data transfer. ABRT shall be set to one if the device is not able to complete the action requested by the command. ABRT shall be set to one if an address outside of the range of user-accessible addresses is requested if IDNF is not set to one.

LBA Low, LBA Mid, and LBA High, Device

Shall be written with the address of first unrecoverable error.

Status register

BSY will be cleared to zero indicating command completion

DRDY will be set to one.



DF (Device Fault) will be set to one if a device fault has occurred.

DRQ will be cleared to zero

ERR will be set to one if an Error register bit is set to one.

5.1.17.5 Prerequisites

DRDY set to one. The host shall initialize the DMA channel.

5.1.17.6 Description

The Write DMA command allows the host to write data using the DMA data transfer protocol.

5.1.18 Execute Device Diagnostic

5.1.18.1 Command Code

90h

5.1.18.2 Feature Set

General feature set

5.1.18.3 Protocol

Device diagnostic

5.1.18.4 Inputs

Only the command code (90h). All other registers shall be ignored.

Table 63: Execute device diagnostic command for inputs information

Register	7	6	5	4	3	2	1	0	
Features	Na								
Sector Count	Na								
LBA Low	Na	Na							
LBA Mid	Na								
LBA High	Na								
Device	obs	Na	obs	Na	Na				
Command	90h								

Device -

DEV shall be ignored.

Normal Outputs

The diagnostic code written into the Error register is an 8-bit code.

Table 64: Execute device diagnostic command for normal outputs information

Register	7	6	5	4	3	2	1	0		
Error	Diagno	Diagnostic Code								
Sector Count	Signatu	Signature								
LBA Low	Signatu	Signature								
LBA Mid	Signatu	re								
LBA High	Signatu	re								
Device	Signatu	re								
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR		

Error register-



Diagnostic Code

Sector Count, LBA Low, LBA Mid, LBA High, Device registers

Device signature

Device register

DEV shall be cleared to zero.

Status register

TBD

Table 65: Execute device diagnostic command for status register information

Code	Description
01h	Device passed
Others	Device failed

5.1.18.5 Error Outputs

Table 10 shows the error information that is returned as a diagnostic code in the Error register.

5.1.18.6 Prerequisites

This command shall be accepted regardless of the state of DRDY.

5.1.18.7 Description

This command shall cause the devices to perform the internal diagnostic tests.

5.1.19 Security Set Password

5.1.19.1 Command Code

F1h

5.1.19.2 Feature Set

Security Mode feature set

5.1.19.3 Protocol

PIO data-out

5.1.19.4 Inputs

Table 66: Security set password command for inputs information

Register	7	6	5	4	3	2	1	0	
Features	Na								
Sector Count	Na								
LBA Low	Na	Na							
LBA Mid	Na								
LBA High	Na								
Device	obs	Na	obs	Na	Na				
Command	F1h								

Device -

DEV shall specify the selected device.

Normal Outputs

Table 67: Security set password command for normal outputs information

Register	7	6	5	4	3	2	1	0



ur imagination									
Error	Na								
Sector Count	Na								
LBA Low	Na								
LBA Mid	Na	Na							
LBA High	Na								
Device	obs	Na	obs	DEV	Na				
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR	

DEV shall indicate the selected device.

Status register

BSY will be cleared to zero indicating command completion

DRDY will be set to one.

DF (Device Fault) will be set to zero.

DRQ will be cleared to zero

ERR will be set to zero.

5.1.19.5 Error Outputs

Table 68: Security set password command for error outputs information

Register	7	6	5	4	3	2	1	0	
Error	Na	Na	Na	Na	Na	ABRT	Na	Na	
Sector Count	Na								
LBA Low	Na	Na							
LBA Mid	Na								
LBA High	Na								
Device	obs	Na	obs	DEV	Na				
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR	

Error Register

ABRT may be set to one if the device is not able to complete the action requested by the command

Device register

DEV shall indicate the selected device.

Status register

BSY will be cleared to zero indicating command completion

DRDY will be set to one.

DF (Device Fault) should be set to one if a device fault has occurred.

DRQ will be cleared to zero

ERR will be set to one if an Error register bit is set to one.

5.1.19.6 Prerequisites

DRDY set to one.

5.1.19.7 Description

This command transfer 512 byte of data from the host. Table 10 defines the content of this



information. The data transferred controls the function of this command. Table 11 defines the interaction of the identifier and security level bits.

The revision code field shall be returned in the IDENTIFY DEVICE word 92. The valid revision codes are 0001h through FFFEh. A value of 0000h or FFFFh indicates that the Master Password Revision Code is not supported.

Table 69: Security set password command's data content

Word	Content
0	Control Word
	Bit 0 Identifier 0=set User password
	1=set Master password
	Bits (7:1) Reserved
	Bit(8) Security level 0=High
	1=Maximum
	Bits(15:9) Reserved
1-16	Password(32 bytes)
17	Master Password Revision Code()
18-255	Reserved

Table 70: Security Set password command's identifier and security level bit interaction

Identifier	Level	Command result
User	High	The password supplied with the command shall be saved as the new
		User password. The Lock mode shall be enabled from the next
		power-on or hardware reset. The device shall than be unlocked by
		either the User password it the previously set Master password.
User	Maximum	The password supplied with the command shall be saved as the new
		User password. The lock mode shall be enabled from the next power-on
		or hardware reset. The device shall then be unlocked by only the User
		password. The Master password previously set is still stored in the
		device but shall not be unlock
Master	High or	This combination shall set a Master password but shall not enable or
	Maximum	disable the Lock mode. The security level is not changed. Master
		password revision code set to the value in Master Password Revision
		Code field.

5.1.20 Security Unlock

5.1.20.1 Command Code

F2h

5.1.20.2 Feature Set

Security Mode feature set

5.1.20.3 Protocol

PIO data-out



5.1.20.4 Inputs

Table 71: Security unlock command for inputs information

Register	7	6	5	4	3	2	1	0	
Features	Na								
Sector Count	Na								
LBA Low	Na	Na							
LBA Mid	Na								
LBA High	Na								
Device	obs	Na	obs	Na	Na				
Command	F2h								

Device register-

DEV shall specify the selected device.

Normal Outputs

Table 72: Security unlock command for inputs information

Register	7	6	5	4	3	2	1	0		
Error	Na	Na								
Sector Count	Na	la								
LBA Low	Na	Na								
LBA Mid	Na									
LBA High	Na									
Device	obs	Na	obs	DEV	Na					
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR		

Device register

DEV shall indicate the selected device.

Status register

BSY will be cleared to zero indicating command completion

DRDY will be set to one.

DF (Device Fault) will be set to zero.

DRQ will be cleared to zero

ERR will be set to zero.

5.1.20.5 Error Outputs

The device shall return aborted if the device is in Frozen mode.

Table 73: Security unlock command for inputs information

Register	7	6	5	4	3	2	1	0
Error	Na	Na	Na	Na	Na	ABRT	Na	Na
Sector Count	Na							
LBA Low	Na							
LBA Mid	Na							
LBA High	Na							
Device	obs	Na	obs	DEV	Na			



Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR

Error Register

ABRT may be set to one if the device is not able to complete the action requested by the command

Device register

DEV shall indicate the selected device.

Status register

BSY will be cleared to zero indicating command completion

DRDY will be set to one.

DF (Device Fault) should be set to one if a device fault has occurred.

DRQ will be cleared to zero

ERR will be set to one if an Error register bit is set to one.

5.1.20.6 Prerequisites

DRDY set to one.

5.1.20.7 Description

This command transfers 512 bytes of data from the host. Table13 defines the content of this information. If the Identifier bit is set to Master and the device is in high security level, then the password supplied shall be compared with the stored Master password. If the device is in maximum security level then the unlock shall be rejected.

If the Identifier bit is set to user then the device shall compare the supplied password with the stored User password. If the password compare fails then the device shall return command aborted to the host and decrements the unlock counter. This counter shall be initially set to five and shall decremented for each password mismatch when SECURITY UNLOCK and SECURITY ERASE UNIT commands shall be command aborted until a power-on reset or a hardware reset. SECURITY UNLOCK commands issued when the device is unlocked have no effect on the unlock counter.

5.1.21 Security Erase Prepare

5.1.21.1 Command Code

F3h

5.1.21.2 Feature Set

Security Mode feature set

5.1.21.3 Protocol

Non-data

5.1.21.4 Inputs

Table 74: Security erase prepare command for inputs information

Register	7	6	5	4	3	2	1	0
Features	Na							
Sector Count	Na							
LBA Low	Na							



LBA Mid	Na				
LBA High	Na				
Device	obs	Na	obs	Na	Na
Command	F3h				

DEV shall specify the selected device.

Normal Outputs

Table 75: Security erase prepare command for normal outputs information

Register	7	6	5	4	3	2	1	0
Error	Na							
Sector Count	Na							
LBA Low	Na							
LBA Mid	Na							
LBA High	Na							
Device	obs	Na	obs	DEV	Na	Na	Na	Na
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR

Device register

DEV shall indicate the selected device.

Status register

BSY will be cleared to zero indicating command completion

DRDY will be set to one.

DF (Device Fault) will be set to zero.

DRQ will be cleared to zero

ERR will be set to zero.

5.1.21.5 Error Outputs

The device shall return aborted if the device is in Frozen mode.

Table 76: Security erase prepare command for error outputs information

Register	7	6	5	4	3	2	1	0
Error	Na	Na	Na	Na	Na	ABRT	Na	Na
Sector Count	Na							
LBA Low	Na							
LBA Mid	Na							
LBA High	Na							
Device	obs	Na	obs	DEV	Na			
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR

Error Register

ABRT shall be set to one if the device is in Frozen mode. ABRT may be set to one if the device is not able to complete the action requested by the command

Device register

DEV shall indicate the selected device.



Status register

BSY will be cleared to zero indicating command completion

DRDY will be set to one.

DF (Device Fault) should be set to one if a device fault has occurred.

DRQ will be cleared to zero

ERR will be set to one if an Error register bit is set to one.

5.1.21.6 Prerequisites

DRDY set to one.

5.1.21.7 Description

The SECURITY ERASE PREPARE command shall be issued immediately before the SECURITY ERASE UNIT command to enable device erasing and unlocking. This command prevents accidental loss of data on the device.

5.1.22 Security Erase Unit

5.1.22.1 Command Code

F4h

5.1.22.2 Feature Set

Security Mode feature set

5.1.22.3 Protocol

PIO data-out.

5.1.22.4 Inputs

Table 77: Security erase unit command for inputs information

					•			
Register	7	6	5	4	3	2	1	0
Features	Na							
Sector Count	Na							
LBA Low	Na							
LBA Mid	Na							
LBA High	Na							
Device	obs	Na	obs	Na	Na	Na	Na	Na
Command	F4h							

Device register-

DEV shall specify the selected device.

Normal Outputs

Table 78: Security erase unit command for normal outputs information

Register	7	6	5	4	3	2	1	0
Error	Na							
Sector Count	Na							
LBA Low	Na							
LBA Mid	Na							
LBA High	Na							



Device	obs	Na	obs	DEV	Na	Na	Na	Na
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR

DEV shall indicate the selected device.

Status register

BSY shall be cleared to zero indicating command completion

DRDY shall be set to one.

DF (Device Fault) will be set to zero.

DRQ shall be cleared to zero

ERR shall be cleared to zero.

5.1.22.5 Error Outputs

The device shall return aborted if the device is in Frozen mode, not preceded by a SECURITY ERASE PREPARE command, if Enhance Erase is specified but not supported, or if the data area is not successfully overwritten.

Table 79: Security erase unit command for error outputs information

Register	7	6	5	4	3	2	1	0
Error	Na	Na	Na	Na	Na	ABRT	Na	Na
Sector Count	Na							
LBA Low	Na							
LBA Mid	Na							
LBA High	Na							
Device	obs	Na	obs	DEV	Na			
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR

Error Register

ABRT shall be set to one if the device is in Frozen mode, not preceded by a SECURITY ERASE PREPARE command, or if the data area is not successfully overwritten. ABRT may be set to one if the device is not able to complete the action requested by the command.

Device register

DEV shall indicate the selected device.

Status register

BSY will be cleared to zero indicating command completion

DRDY will be set to one.

DF (Device Fault) should be set to one if a device fault has occurred.

DRQ will be cleared to zero

ERR will be set to one if an Error register bit is set to one.

5.1.22.6 Prerequisites

DRDY set to one. This command shall be immediately preceded by a SECURITY ERASE PREPARE command.

5.1.22.7 Description

This command transfer 512 bytes of data from the host. Table12 defines the content of this



information. If the password does not match the password previously saved by the device, the device shall reject the command with command aborted.

The SECURITY ERASE PREPARE command shall be completed immediately prior to the SECURITY ERASE UNIT command. If the device receives a SECURITY ERASE UNIT command without an immediately prior SECURITY ERASE PREPARE command, the device shall command abort the SECURITY ERASE UNIT command.

When Normal Erase mode is specified, the SECURITY ERASE UNIT command shall write binary zeroes to all user data areas. The Enhanced Erase mode is optional. When Enhanced Erase Mode is specified, the device shall write predetermined data patterns to all user areas. In Enhanced Erase mode, all previously written user data shall be overwritten, including sectors that are no longer in use due to reallocation.

This command shall disable the device Lock mode, however, the Master password shall still be stored internally within the device and may be reactivated later a new User password is set.

Word Content 0 Control Word Bit 0 Identifier 0=Compare User password 1= Compare Master password Bit 1 Erase mode 0=Normal Erase 1=Enhanced Erase Bit(15:2) Reserved 1-16 Password (32 Bytes)

Table 80: Security erase unit password information

5.1.23 Security Freeze Lock

17-255

5.1.23.1 Command Code

F5h

5.1.23.2 Feature Set

Security Mode feature set

Reserved

5.1.23.3 Protocol

Non-data.

5.1.23.4 Inputs

Table 81: Security freeze lock for inputs information

Register	7	6	5	4	3	2	1	0
Features	Na							
Sector Count	Na							
LBA Low	Na							
LBA Mid	Na							
LBA High	Na							
Device	Obs	Na	obs	Na	Na	Na	Na	Na



Command	F5	r

DEV shall specify the selected device.

Normal Outputs

Table 82: Security freeze lock for normal outputs information

Register	7	6	5	4	3	2	1	0						
Error	Na													
Sector Count	Na	Na												
LBA Low	Na	Na												
LBA Mid	Na	Na												
LBA High	Na													
Device	Obs Na		obs	DEV	Na	Na	Na	Na						
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR						

Device register

DEV shall indicate the selected device.

Status register

BSY shall be cleared to zero indicating command completion

DRDY shall be set to one.

DF (Device Fault) will be set to zero.

DRQ shall be cleared to zero

ERR shall be cleared to zero.

5.1.23.5 Error Outputs

The device shall return aborted if the device is in Frozen mode, not preceded by a SECURITY ERASE PREPARE command, if Enhance Erase is specified but not supported, or if the data area is not successfully overwritten.

Table 83: Security freeze lock for error outputs information

Register	7	6	5	4	3	2	1	0						
Error	Na Na		Na	Na	Na	ABRT	Na	Na						
Sector Count	Na													
LBA Low	Na													
LBA Mid	Na													
LBA High	Na													
Device	Obs	Na	obs	DEV	Na									
Status	BSY DRDY		DF	Na	DRQ	Na	Na	ERR						

Error Register

ABRT shall be set to one if the device is in locked mode. ABRT may be set to one if the device is not able to complete the action requested by the command.

Device register

DEV shall indicate the selected device.

Status register



BSY will be cleared to zero indicating command completion

DRDY will be set to one.

DF (Device Fault) should be set to one if a device fault has occurred.

DRQ will be cleared to zero

ERR will be set to one if an Error register bit is set to one.

5.1.23.6 Prerequisites

DRDY set to one.

5.1.23.7 Description

The SECURITY FREEZE LOCK command shall set the device to Frozen mode. After command completion any other commands that update the device Lock mode shall be command aborted. Frozen mode shall be disabled by power-off or hardware reset. If SECURITY FREEZE LOCK shall be issued when the device in Frozen mode, the command executes and the device shall remain in Frozen mode.

Command disabled by SECURITY FREEZE LOCK are:

- SECUIRTY SET PASSWORD
- SECURITY UNLOCK
- SECURITY DISABLE PASSWORD
- SECURITY ERASE PREPARE
- SECURITY ERASE UNIT

5.1.24 Security Disable Password

5.1.24.1 Command Code

F6h

5.1.24.2 Feature Set

Security Mode feature set

5.1.24.3 Protocol

PIO data-out.

5.1.24.4 Inputs

Table 84: Security disable password command for inputs information

Register	7	6	5	4	3	2	1	0
Features	Na							
Sector Count	Na							
LBA Low	Na							
LBA Mid	Na							
LBA High	Na							
Device	obs	Na	obs	Na	Na	Na	Na	Na
Command	F6h							

Device register-

DEV shall specify the selected device.

Normal Outputs



Table 85: Security disable password command for normal outputs information

Register	7	6	5	4	3	2	1	0						
Error	Na													
Sector Count	Na													
LBA Low	Na													
LBA Mid	Na	Na												
LBA High	Na	Na												
Device	obs Na		obs	DEV	Na	Na	Na	Na						
Status	BSY	DRDY	DF	Na	DRQ	Na	Na	ERR						

DEV shall indicate the selected device.

Status register

BSY shall be cleared to zero indicating command completion

DRDY shall be set to one.

DF (Device Fault) will be set to zero.

DRQ shall be cleared to zero

ERR shall be cleared to zero.

5.1.24.5 Error Outputs

The device shall return aborted if the device is in Locked mode, or device is in Frozen mode.

Table 86: Security disable password command for error outputs information

Register	7	6	5	4	3	2	1	0						
Error	Na Na I		Na	Na	Na	ABRT	Na	Na						
Sector Count	Na													
LBA Low	Na	Na												
LBA Mid	Na	Na												
LBA High	Na													
Device	obs	Na	obs	DEV	Na									
Status	BSY DRDY		DF	Na	DRQ	Na	Na	ERR						

Error Register

ABRT may be set to one if the device is not able to complete the action requested by the command.

Device register

DEV shall indicate the selected device.

Status register

BSY will be cleared to zero indicating command completion

DRDY will be set to one.

DF (Device Fault) should be set to one if a device fault has occurred.

DRQ will be cleared to zero

ERR will be set to one if an Error register bit is set to one.

5.1.24.6 Prerequisites



DRDY set to one. Device shall be in Unlocked mode.

5.1.24.7 Description

The SECURITY DISABLE PASSWORD command transfer 512 bytes of data from the host. Table 13 defines the content of this information. If the password selected by word 0 matches the password previously saved by the device, the device shall disable the Lock mode. This command shall not change the Master password. The Master password shall be reactivated when a User password if set.

Table 87: Security disable password command content

Word	Content
0	Control Word
	Bit 0 Identifier 0=Compare User password
	1= Compare Master password
	Bit(15:1) Reserved
1-16	Password (32 Bytes)
17-255	Reserved

6. Part Number Rule

0005	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
CODE	D	1	S	S - 0 8 G		G	J	3	0	Α	С	Α	Q	S						
Description	Disk								С	Categ	ory	FW	Operation Temp.	Internal Control	CH.	Flash	-	Customized Code		
										Defi	niti	ion								
Code 1 st (Disk)									Code 13 th (Operation Temperature)											
D : Disk									C:	Stan	dard	Grade (0°	C~ +70°C)							
Code 2 nd ~ 4 th (Form Factor)							W: Industrial Grade (-40°C ~ +85°C)													
1SS: SATA Sli	m D1	50Q E	BGA						K: Standard Grade with coating											
С	ode (6 th ~8	3 th (C	apa	city	')			T: Industrial Grade with coating											
02G: 2GB									Code 14 th (Internal control)											
04G: 4GB									Code 15 th (Channel of data transfer)											
08G:8GB									S: Single Channel											
16G: 16GB									D: Dual Channels											
32G: 32GB									Q: Four Channels											
C	Code	9 th ~	11 th	(Seri	ies))			Code 16 th (Flash Type)											
J30: SATA Slir	n D15	0Q, D	150 s	eries					S: Samsung SLC											
Code 12 th (Firmware version)							T: Micron SLC													
A: Standard F/	A: Standard F/W version														-	-				
									<u> </u>											



Verification of Compliance

Product Name : SATA Slim Series

Model Number : D1SS-XXXJXXXXXX
Applicant : InnoDisk Corporation

Address : 9F., No.100, Sec. 1Xintai5th Rd., Xizhi Dist., New Taipei City

221, Taiwan

Report Number : C22-U070-1101-404

Issue Date : March 3, 2011

Applicable Standards: EN 55022:2006+A1:2007 Class B ITE

EN 55024:1998+A1:2001+A2:2003 EN 61000-4-2:1995+A1:1998+A2:2001

EN 61000-4-3:2006+A1:2008

EN 61000-4-4:2004

Based on the EMC Directive 2004/108/EC and the specifications of the customer, one sample of the designated product has been tested in our laboratory and found to be in compliance with the EMC standards cited above.



TAF 0905

FCC CAB Code TW1053 NVLAP Lab Code 200575-0

IC Code 4699A

VCCI Accep. No. R-1527, C-1609, T-131, T-1441, G-10



Central Research Technology Co.

EMC Test Laboratory 11, Lane41, Fushuen St., Jungshan Chiu, Taipei, Taiwan, 104, R.O.C.

Tel: 886-2-25984568 Fax: 886-2-25984546

(Tsun-Yu Shih/ General Manager)

Date: March 3, 2011



Verification of Compliance

Product Name : SATA Slim Series

Model Number : D1SS-XXXJXXXXXXX
Applicant : InnoDisk Corporation

Address 9F., No.100, Sec. 1Xintai5th Rd., Xizhi Dist., New Taipei City

221, Taiwan

Report Number : F-U070-1101-404

Issue Date : March 3, 2011

Applicable Standards: FCC Part 15, Subpart B Class B ITE

ANSI C63.4:2003

Industry Canada ICES-003 Issue 4 CSA-IEC CISPR22: 02 Class B ITE

One sample of the designated product has been tested in our laboratory and found to be in compliance with the FCC rules cited above.





NVLAP LAB CODE 200575-0

TAF 0905

FCC CAB Code TW1053

IC Code 4699A

VCCI Accep. No. R-1527, C-1609, T-131, T-1441, G-10



Central Research Technology Co.

EMC Test Laboratory 11, Lane41, Fushuen St., Jungshan Chiu, Taipei, Taiwan, 104, R.O.C.

Tel: 886-2-25984568 Fax: 886-2-25984546

(Tsun-Yu Shih/ General Manager)

Date: March 3, 2011